



Commissioning Instructions

WinPQ Evaluation Software and PQI-D/PQI-DA Measuring Systems
WinPQ Para Express (only chapter 9)





Notes on the commissioning instructions:

After installing the **WinPQ** software and the **MySQL** database in sections 2 and 3 of the instructions, select one of the chapters highlighted in colour for data communication between the software and the measuring devices.

The selected section (e.g. 6. Device Connection via TCP/IP) describes the required operating steps for the software and hardware. Any other, alternative chapters for connecting a device can be skipped.

If different communication paths are to be operated in parallel, work through all points of the respective data connections used (e.g. MODEM and TCP/IP).

WinPQ Para Express



Additional to WinPQ there is a small software WinPQ Para Express available only for setup the parameters in PQI-D and PQI-DA. This software is free of charge and available on www.a-eberle.de.

All settings for the hardware could be made with this software. It is possible to check with online data the correct connection of the device. It is possible to start this SW directly from an USB-stick.

Please use all information from chapter 9.

A. Eberle GmbH & Co. KG

Aalener Straße 30/32

D-90441 Nuremberg

Tel.: 0911 / 62 81 08 0

Fax: 0911 / 62 81 08 96

E-Mail: info@a-eberle.de

Internet: www.a-eberle.de

A.-Eberle GmbH & Co. KG cannot be held liable for any damage or losses resulting from printing errors or changes to this operating manual.

Furthermore, **A. Eberle GmbH & Co. KG** does not assume responsibility for any damage or losses resulting from defective devices or from devices altered by the user.

Copyright 2010 by A. Eberle GmbH & Co. KG

All rights reserved.

Content

1.	Introduction	6
2.	Installation of the Software	7
2.1	Index of the used TCP/IP-Ports	7
2.2	Installation of the Database (File Server).....	8
2.3	Installation of a Client (Further Evaluation Computer)	8
2.4	Installation Procedure.....	8
3.	The WinPQ Control Center: The Program PQStart	15
3.1	Representation of PQI-D Devices in PQStart	15
3.1.1	Create new stations, groups and tabs	15
3.1.2	Changing the device name and ID number.....	17
3.1.3	Alerting – Optically, Acoustically, or by E-Mail	17
3.1.4	Hiding of Program Functions	18
3.2	Connecting an additional evaluation computer to the database	19
3.2.1	Connection of a client to the database.....	19
3.2.2	Connection of an additional evaluation computer for online data and parameterization	21
4.	Settings in WinPQ – PQ Admin	21
4.1	Tab: SQL	22
4.2	Tab: User	23
4.3	User with limited rights.....	24
5.	Connection of a device directly with RS232	26
5.1	Setting the device PQI-D or DA	26
5.2	Settings of the PQRS232Server	26
5.3	Settings in the “PQManager”	27
6.	Device Connection via TCP/IP	29
6.1	Setting the interface of the device	29
6.1.1	TCP/IP Connection through W&T COM-Server.....	31
6.2	Settings of the “PQRS232Server”	32
6.3	Settings in the “PQManager”	33
7.	Device Connection via Dial-Up MODEM	35
7.1	Setting the device	35
7.1.1	Setting the interface of the PQI-D	35
7.2	Setting the MODEM on the PQI-D side.....	37
7.3	Setting the Remote MODEM	38
7.4	Settings of the “RS232Server”	38


7.5	Configuration of the WinPQ Software	39
8.	The WinPQ Management Programs in Continuous Operation	40
8.1	Windows Task Scheduler	40
8.2	The Management Programs in Continuous Operation.....	41
8.3	Setting PQManager to Continuous Operation:.....	41
8.4	Setting the PQRS232Server to Continuous Operation	42
8.5	Setting PQRvReport to Continuous Operation:	42
9.	Setup and parameterization – PQI-D/DA.....	42
9.1	Setup with PQ Para Express	42
9.2	Setup with WinPQ.....	43
9.3	ID, LAN, Time	45
9.3.1	Time synchronization.....	45
9.3.2	ECL commands.....	46
9.3.3	ELAN structure	47
9.4	Thresholds, connection, IO	47
9.4.1	Special parameter	48
9.4.2	EN50160 thresholds.....	49
9.4.3	Transnestic.....	50
9.4.4	Option M94/M95 – analogue output	51
9.4.5	Option M97/M98 analogue inputs	52
9.4.6	Binary inputs	53
9.4.7	Messages on Relays and LED’s	54
9.5	Measuring parameter / trigger.....	55
9.5.1	Status of LED’s, relays and binary inputs.....	56
9.5.2	Online panel.....	56
9.5.3	Vector diagram	56
9.5.4	Parameterization of continues classes	57
9.5.5	Parameterisation of disturbance recorder	59
9.5.6	Parameterisation for disturbance recorder.....	60
9.5.7	Parameterization of harmonic recorder RecC.....	61
9.5.8	Parameterisation of RecS.....	62
9.5.9	Parameterization of power quality events	63
10.	Time synchronization	63
10.1	Time synchronisation with DCF77 time clock.....	63
10.2	Time synchronisation with GPS time clock.....	64
10.3	Interface settings for time clock connected to RS232.....	64

10.4	Interface settings for the GPS clock connected at the time bus.....	65
10.5	Setting up the synchronization with E-LAN connection	65
11.	Firmware update PQI-D and PQI-DA	67
12.	Setting of the PQ-Mail	71
13.	Automatically print or e-mail order.....	72
13.1	Automatically generated disturbance reports.....	72
13.2	Automatic power quality reports.....	73
13.3	Mail order automatic reports	74

1. Introduction

The **WinPQ** software can be used to manage a large number of pre-installed PQI-Ds/DAs. The devices can communicate via different communication paths with **WinPQ**. The high degree of system flexibility, however, requires a certain degree of care when installing the software.

The overview graphic on the following page shows a situation with three computers and indicates which software module must be installed on which computer. Of course, the overhead is reduced if the application runs only on a single computer.



Remark on the excessive use of the word "Server":

File server: Computer on which the "MySQL" database runs and data are stored.

RS232Server: Part of the "WinPQ" software program which handles communication of the individual **WinPQ** programs with the devices.

MySQL server or database server: MySQL is an "SQL server", i.e. database software for managing large amounts of data. MySQL runs on the file server.

COM server: Hardware, e.g. from W&T. This is an adaptor between RS232 and TCP/IP, which is used whenever PQI-Ds are to be connected via a network.

The REGSys devices "REG-PE" and "REG-P" (control system connection) also have this functionality.

The term "server" is avoided in these instructions. The respective term from this list is used instead. Thus it is always clear which server is meant.

2. Installation of the Software

The WinPQ software package mainly comprises two components: the SQL server and the visualisation software. A complete installation only needs to be carried out on the file server. Only the WinPQ visualisation software without database needs to be installed on the control station and connection PC.

2.1 Index of the used TCP/IP-Ports

The following table shows a list of all TCP/IP-Ports used in this System. Depending from your system configuration and the hardware the ports can be different.

Programm	Zweck	Server/ Client	Vorschlag	Kommunikation mit ...	Änderung
MySQL (service)	Communication with MySQL- database server	Server	3306	PQManager, PQVisu, PQStart, PQReport	
RS232Server (service)	Remote Parametrization (Changing RS232- Parameter)	Server	8000	Telnet	INI-File
RS232Server (service)	Access RS232-Ports	Server	1701, 1702 usw.	PQManager, PQPara	INI-File, PQStart
PQReport, PQVisu, PQStart	Read and visualize of MySQL-data	Client	3306	MySQL-service	
PQPara	Read and change of PQI-D setup	Client	1701 usw. 8000 ...	RS232Server WuT-COM-Server	INI-File
PQManager	Transfers data from E-LAN Into SQL-database	Client Client	1700 ... 3306	RS232-/COM-Server MySQL-service	INI-File
WuT-COM	COM-Server- parametrization Communication to E-LAN	Client Client	1111 8000 8888	Telnet PQManager, PQPara Software-COM-Server- Reset	Fix COM-SVR
Remote Desk- top RDP	Access via „Remote Desk- top“ (MS- Windows ©)		3389	Remote access via oper- ating system abilities	

Overview of program components

2.2 Installation of the Database (File Server)

Installation of the complete package on the file server.


Proceed as described in section 2.3 of these instructions.

Note down the IP address or the BIOS name of the file server.

In some circumstances, the Windows command "IPCONFIG" may be useful.

2.3 Installation of a Client (Further Evaluation Computer)


When installing an additional evaluation computer without a database, the client accesses the database on the file server (alternatively it's possible to transfer the '..\winpq' directory by Copy & Paste to the next computer). Proceed as described in the next section of these instructions. Activate the option **'Continue without installation of MySQL-Database'** in the dialog below.




Main menu of the installation screen

2.4 Installation Procedure


The file winpq.exe is supplied on the installation CD. It is a self-extracting installation file, which is unzipped and started by double-clicking on it (or by selecting it and pressing ENTER). First, the usual start screen form is displayed. If no license number or an invalid license number is entered three times in a row, the software can be installed and used as a **DEMO** version. This version is restricted, access to real PQI-D stations is not possible.




First you find the usual welcome dialog.




You should then read the license agreement carefully and accept it.




Then a few notes on carrying out the installation are displayed.



Now the software can be registered under your name.




Select a different directory if it's necessary. Less than 300 MB of disk space (including the setting data or device profiles created subsequently by the user) are required. The save location of the actual measurement data is not defined here. The amount of data generated by the PQI-D stations can be ignored here.




The installation process is now in progress. This can take 1 to 5 minutes, depending on the computer's speed.

Once all of the data have been copied, a tool from the **WinPQ** environment is automatically started. This can be used to set up the future program behaviour. Therefore do never change the check box 'Run WIPQ now'.




Before further steps can be taken, the license number must first be entered. This can be found on the license certificate in the folder containing the documentation. If no license number or an invalid license number is entered three times in a row, the software can be installed and used as a **DEMO** version. This version is restricted, access to real PQI-D stations is not possible.





Installation screen license code

The following screens support the installation of the **MySQL**-database-server and important options of the basic setup can be selected. But before the next step can be launched, you have to read and accept the **MySQL** license agreement as an **embedded version** into the software package **WinPQ**. Notice the buttons have the same numbers like the text in the memo below.




With the button „Installation of the MySQL-Dateabase-server“ the installation procedure of the **MySQL**-Database-server will be started. All necessary files will be unzipped into the sub folder '..\winpq\MySQL' of the installation path.







It's possible to select a different folder (assume a memory of about 500MB per Station and year) for the database data (e.g. a drive with more available memory). If this isn't necessary continue directly with button 2.2.2.




The following button 2.2.2 have to be executed in any case. The **MySQL**-service program will be installed, started and PQ-MySQL-users will be established. For the user '**root**' the password '**admin**' will be set.



Right now the delivered DEMO-Data can be transferred into a SQL database. This data can be operated from a database with the name '**PQ_DEMO**'.



Afterwards the installations routine changes to the page 'Basic-setup'. Mostly you can left the selection unchanged. If you want to operate in a an multi user environment (e.g. Citrix) with different setup of each user or several user at the same time the selection %UserProfile% is recommended. By confirming the selection the third page will be activated.




Several important settings can be made via the following screen form.

To differentiate between the station data, the ID of the **PQI-D** stations is usually used. When parameterising the stations, ensure that IDs are not used twice, even if stations are not to be interconnected via the **E-LAN**. "**Extended ID**" means that this restriction is removed insofar as the station name (8 characters) is used in addition to the ID.

In the centre area, important settings can be made regarding data access to the stations. An interface for direct access via RS232, a second one for communication using a MODEM, and a TCP/IP interface can be stored and parameterised. Based on these examples, further ports can subsequently be added directly in the INI file of the "**PQRS232Server**" by means of copy and paste. With the checkbox "**Time syn. via PC**", it is defined that the **PQI-D** stations are synchronised daily with the PC time. The behaviour of the program is adapted to the preferred mode of operation by selecting "**Access to PQI-D stations**" (on the right).

Finally, your company name can be entered. An image file with your logo can be assigned (the formats "**jpg**" and "**bmp**" are supported) later in the **PQAdmin** program (Tab: User setup). These settings are used for protocol printouts and similar.

3. The WinPQ Control Center: The Program PQStart



This program represents the communication centre of **WinPQ**. Each individual PQI-D/DA is represented by a field which permits you to access the station directly. The most important functions of this program are:

- Display of the identifier and any text that describes the associated station
- Via the menu (in the figure "SS1", the text can be set as required), direct access to the station-related data in the database or the station itself
- Setting for access via MODEM
- It alerts the user when new PQ events/errors occur
- It reports PQ events and changes at the binary inputs

3.1 Representation of PQI-D Devices in PQStart

You can create a box for each device from which you can access the device directly. The station properties and labeling must be adapted to make it as easy as possible for subsequent users to assign the station. Right-click on the required station. Select "Properties: station" in the menu that appears. The central dialogue box for the link between this display and the devices is then displayed.


3.1.1 Create new stations, groups and tabs

By clicking the right mouse button you have the following options:

Station: Activate	A station can be activated
Station: Properties	You can change the properties of each station
Station: Copy setup	You can copy the setup into clipboard
Station: Insert setup	You can insert properties from clipboard
Station: New	One can create a new station
Station: Delete	A station can be deleted here
Group: Properties	The properties of a group (sub station) can be changed


We take care of it

Group: New	A new group can be generated
Page: Change text	The text of the page tab can be changed
Search for a station	One can input a station name and the program searches for the item



An example of station overview

3.1.2 Changing the device name and ID number



The most important points:


- The designations which you can enter in the field do not change your device settings. It is therefore not absolutely essential for the designation and the device name to be identical. The ID (e.g. "Q1") must be entered correctly, because this ID is used as a filter when a program is started.
- In the field "Connections (SQL + TCP/IP)", the connection to the **RS232Server** is generated by means of "Network-ID" and "Network port", i.e. the direct access to the device for parameterisation and online data.
- The link to the database in the same field is created with "SQL connection" and "IP...". "SQL connection" indicates which data are to be used.

PQVisu	Standard directory for PQI-D measurement data
PQDemo	Demo data for exemplifying and testing
PQBox	Data of the PQ-Box 1000 measuring devices


- Select the SQL connection "**PQVisu**" as the default setting.
- The standard network ID is called "**LocalHost**" if the program PQRS232Server runs on the same PC.

3.1.3 Alerting – Optically, Acoustically, or by E-Mail

This permits alerting (optically and acoustically) when fault messages or binary signals (binary inputs of the PQI-D) are received.




In the dialogue box "Alert/Mail" you can set different alerting options for events on the PC.



Recommendation: Recorder B – Optical alert

3.1.4 Hiding of Program Functions

The scope of the menu functions can be limited.



As with all other selection boxes, if no selection has been made, all functions and data can be accessed.


3.2 Connecting an additional evaluation computer to the database

3.2.1 Connection of a client to the database

Option 1:

Open the station properties of any device.

If no database is found, the button "IP" is activated. When this is clicked, an input window appears, into which the BIOS name or IP address of the server on which the database is installed can be entered.




A connection has been established as soon as the status box on the bottom left is green. If it remains red, either the address is incorrect or there is a problem with the network. (For instance Firewall! Refer to the network checklist)

In the Network-ID field, enter the address of the computer on which the program PQRS232Server is running. (Default setting "LocalHost")

We take care of it


Option 2:

Open the file ..\WinPQ\dbxconnections.ini



After each "HostName=", enter the IP or the BIOS name of the file server.

For example, HostName=StWX_Server1 or HostName= 192.168.1.1



If the PQStart program finds the database, the colour of status box on the bottom left is green and displays:

"SQL: [PQID@Servername](#)"


Information for the administrator:

To contact the SQLServer, the clients use Port 3306. If you set the "SQL connection" to PQDemo, demo data are displayed which will help you become accustomed in the beginning when actual data is not available yet.

3.2.2 Connection of an additional evaluation computer for online data and parameterization


These settings are only required if you want to access devices (PQI-D/-DA) **online** from this client. A functional access to the database is sufficient for visualising data.

Open the station properties.



In the Network-ID field, enter the IP address or the BIOS name of the computer on which the **PQRS232Server** is running. Select the device you want to address via the port number (in the field on the right) in accordance with the specifications made in the program **PQRS232Server**.

4. Settings in WinPQ – PQ Admin



We take care of it

Using the “PQAdmin” part of the program, it is possible to implement changes in the communication settings, program language, etc. even after installation.




4.1 Tab: SQL

In the menu “Tab: SQL”, it is possible to change settings in the database as well as to save measurement data of the database on another drive.

Backup data	Copy the measurement data of the database to another drive
Restore data	Restore the measurement data in the database
Archive data	Measurement data are copied to another folder and deleted in the source file

4.2 Tab: User

User-specific settings can be made in the menu "User".




General: The language and company name, as well as the selection of authorisations, can be set here.


Graphic: Under the tab "Graphic", a company logo can be set for all printed reports and fault records.

4.3 User with limited rights

In "WinPQ / PQ Admin" it is possible to setup two user groups with limited rights. If one user should not have access to the setup of the devices, the adjustments can be made here




1) The access to "WinPQ Admin" is not allowed for the user with limited administration rights.





2) Only the icons with user rights are shown in WinPQ

In this example no parameters or thresholds of the hardware can be changed



3) To enable all administration or operator rights it is necessary to insert the password. After the password is inserted all functions are available.



The entry comprises the following:

PQ111	Use the COM 11 interface of the computer.
115200	Baud rate for communication (default setting in the device)
8	8 data bit (default setting in the device)
1	1 stop bit (default setting in the device)
NONE	No parity (default setting in the device)
RTSCTS	The handshake procedure (default setting in the device)
1711	Port number with which the WinPQ programs access this connection later.
600	Time interval in seconds for synchronising the device with the PC time. No value must be entered in case of external time synchronisation.


Usually, only the following three variables must be adapted:

1. The COM port: Right after "PQI", enter the COM port of the PC to which the device is connected. For COM 2, you should enter **PQI2**, for COM 27 you should enter **PQI27**, etc.
2. The port number of the client: This port number is the distinguishing feature for the **WinPQ** programs to address the required device. (See figure Overview in chapter 1). It should therefore be ensured that there is a different port number for each connection entered.
3. We suggest 1701 as the first port number.
4. Time synchronisation: This number (600 in the example) is the interval in seconds for synchronising the PC time/PQI-D time. You can deactivate the time synchronisation via PC by deleting this number. This is especially required if a DCF clock sets the time for the device.

Never delete one of the semicolons.

5.3 Settings in the "PQManager"

The **PQManager** archives the measurement data of the network analysers in the database. Each communication from **PQRS232Server** will be automatically copied to **PQManager**. For standard installations no work has to be done here.



Entries in the PQManager:

Offline=0	“PQManager” operates continuously and reads measurement data from the PQI devices.
Offline=1	PQManager is automatically closed following data transmission from the devices.
CLOSEENDOFDAY=3	In cases of continuous operation, we recommend that you exit the “PQManager” once per day and reopen it via Windows “ Scheduled task ”. The number 3 here represents the time in minutes before midnight at which the program will be closed.
PASSWORD=	A password can be set up here if unintentional closing of the program “PQManager” is to be prevented.

6. Device Connection via TCP/IP

6.1 Setting the interface of the device

Agree with the network administrator on a free IP address which can be permanently assigned to the device. Also make a note of the subnet mask of your network. Make an additional note of the MAC of the device. This can be found on the name plate.


If the connection to your office network is via a router (gateway, bridge), also make a note of the IP address of the router.

If you connect the device direct to your laptop computer, use a crossover cable, not a patch cable.

TCP/IP Connection with PQI-DA (also Reg-P)


Connect your laptop computer and the device with a crossover cable.

Start the program "Reg-P-Loader". The following dialogue box is displayed



1. Set the MAC address which is specified on the name plate of the device.
2. Select the network connection to which the device is connected. This is usually an "LAN connection".

Then switch to the second tab.



3. Read out the COM-Server parameters.
4. Enter the required IP address.
5. After entering the values, click the button “Transfer new parameters”.

If the message “Transfer successful” appears, the device has been parameterised.

Note:

IP address: The IP address of the measuring device (PQI-DA) which you agreed on with the system administrator.

Subnet mask: Subnet mask of your network.

The IP address of the default gateway: If the device is connected via a gateway (router, bridge), then enter its address here.

If no gateway is required, enter the address 0.0.0.0.


TCP port (data transfer): The port via which communication takes place. The default setting is 1023.

T-O: For the first character = 240

T-O: Between the characters = 36

6.1.1 TCP/IP Connection through W&T COM-Server

Connect your laptop computer to the COM-Server (REG-COM) by means of a crossover cable. Start the program "WuTility.exe". Click on the icon "Scan". Your COM-Server with the currently set IP address is displayed. To set the IP address, select the entry and click the icon "IP address". The following dialogue box is displayed:

Change Network Parameters

IP address (must be unique): 192 . 168 . 1 . 216 Address range: No restrictions

The device's current IP address:

Caution!

On a TCP/IP network, there must never be two devices with the same IP address. Please make sure that the above IP address has not been assigned to someone else, and that it is not part of a DHCP address pool, either.

When in doubt about available addresses, ask your network administrator.

Subnet mask: 255 . 255 . 255 . 0 Default values from...: Device settings

Default gateway: 192 . 168 . 1 . 5

< Zurück Weiter > Abbrechen

IP address: The first three fields of the IP address are deactivated by default. If you need to access one of these three fields, select "No restrictions" in the drop-down list "Address range" to gain access.


Subnet mask: Enter the value specified by the system administrator. 255.255.255.0 is the default value.

Standard gateway: Enter the value specified by the system administrator here. If no gateway is used, enter 0.0.0.0.

After clicking on "Next", BootP is requested; this should be deactivated. After clicking on "Next" again, a message is displayed indicating that the COM-Server can now be used and that the new IP address has been adopted.

6.2 Settings of the “PQRS232Server”

The “PQRS232Server” handles the data connections to the network analysers installed in the field. It establishes the MODEM or TCP/IP connections.



The figure above shows a common entry for two TCP/IP network connections.

The entry comprises the following:


IP1	The connection name. It must begin with “IP”, followed by any number for differentiation
192.168.0.20	The IP address of the device to be addressed (i.e. PQI-DA or REG-PE or COM Server)
8000 ----- 1023	Port number W&T for communication between WinPQ and device Port number PQI-DA (REG-P) for communication between WinPQ and device
1701	Port number for communication between the client and PQRS232Server.
600	Time interval in seconds for synchronising the device with the PC time.

Information: settings interface COM2 of the device:

PQI-DA (REG-P)	W&T Com-Server
COM-Port2:	COM-Port2:
Modus ECL	Mode ECL
Baudrate 115200	Baud rate 57600
Parity P-	Parity P-
Protokoll RTS(CTS)	Protocol RTS(CTS)

6.3 Settings in the “PQManager”

The **PQManager** archives the measurement data of the network analysers in the database. Each communication from PQRS232Server will be automatically copied to PQManager. For standard installations no work has to be done here.



SQL Help

Tab: SQL Tab: User Tab: RS232 Tab: Ini setup

Save INI Start program C:\Programme\WinPQ\INI\PQManager.INI

Setup of the parameterization software
[ID, LAN and Time \(PQParaSys.ini\)](#)
[Connection to the mains, transformer and IO \(PQParaConf.ini\)](#)
[Data classes and trigger \(PQParaClass.ini\)](#)
[Online and offline data \(PQParaVisu.ini\)](#)
[Compact, only the most important parameter \(PQParaComp.ini\)](#)

Transfer of measuring data to the SQL database
[Setup of PQRS232Server \(PQRS232Server.ini\)](#)
[Setup of PQManager \(PQManager.ini\)](#)

Setup of other programs
[General WINPQ setup \(WinPQ.ini\)](#)
[Behaviour of PQStart program \(PQStart.ini\)](#)
[Behaviour of PQReport program \(PQReport.ini\)](#)
[Mail program to send automatically generated reports \(PQMail.ini\)](#)
[Continues backup of the SQL database \(PQBackup.ini\)](#)
[Global SQL-database-access \(dbxconnections.ini\)](#)

Direct change of the items in text editor

```
[PROGRAM]
WINDOWSTATE=1
LOGFILE=1
RS232Start=1
OFFLINE=1
SAVECONFIG=168
CLOSEENDOFDAY=0
FILEERASE=5
MAXRUNTIME=0
PROGAFTREREADY=
SQLDEFAULT=PQManager
INTERVAL=1500
MAIL=
PASSWORD=
CONTRADEDIR=
CLASSDEFAULT=
TRAYICON=1

[PQIHOSTS]
PQI1=LocalHost;1711;BIN
```

Here there is an entry for each data connection to a measuring device.

SQL Status

Entries in the PQManager:

Offline=0	"PQManager" operates continuously and reads measurement data from the PQI devices.
Offline=1	PQManager is automatically closed following data transmission from the devices.
CLOSEENDOFDAY=3	In cases of continuous operation, we recommend that you exit the "PQManager" once per day and reopen it via Windows " Scheduled task ". The number 3 here represents the time in minutes before midnight at which the program will be closed.
PASSWORD=	A password can be set up here if unintentional closing of the program "PQManager" is to be prevented.

7. Device Connection via Dial-Up MODEM

When using a MODEM, there are two options:

1. The MODEM is only used for collecting data. This means that the connection is always established from the control centre and not by the MODEM on the PQI-D side.
2. In case of an automatic disturbance record quickly after the event, the MODEM on the PQI-D side should establish a connection autonomously and transfer the disturbance recordings and EN messages.


7.1 Setting the device

7.1.1 Setting the interface of the PQI-D

In "PQStart", start the program "ID, LAN, Time".

Under the first tab, "Configuration", you can see the required settings for the two serial interfaces of the device. Set the corresponding variables for the interface to which the MODEM is connected.

Example COM 2: ECL, 38 400 baud, P- and XON(XOFF)




Click the "Set" button in the dialogue box of the respective port (COM-Port1; COM-Port2).

Activating the automatic call

If you only use your MODEM to collect data without automatic call-back, you can skip the following sections and go directly to section "Settings MODEM on PQI-D side"

The automatic call by the MODEM when an event occurs is implemented as a background program. There are two types of connection possible:

1. The MODEM is connected to a PQI-D (standard scenario):



Case 1: the MODEM is connected to a PQI-D

identification data: Communication | Time synchronization | ECL commands | E-LAN structure

Station parameter

COM-Port1: Mode: ECL, Baud rate: 115200, Parity: P-, Protocol: RTS(CTS), Set

COM-Port2: Mode: ECL, Baud rate: 115200, Parity: PE, Protocol: XON(XOFF), Set

MODEM callback: Time default callback: 02:30, Connection MODEM: COM1/Front, COM2, Device ID MODEM: Local station, Dial string + number: ATX3D0123.., Used resources: Register: B1..B7, Programs: HD+P20..P26, Function disabled, Set

E-LAN-Left: Termination: Yes, No, Set

E-LAN-Right: Termination: Yes, No, Set

Time for the daily automatic data transfer from the device to the database


String and phone number of the modem connected to the PC

„Function disabled“, switch off the modem function


With „Set“, the settings will be transferred to the device

Case 2: the MODEM is connected to another REGSys device

The MODEM is not connected directly to a PQI-D device in the E-LAN. It is connected to a voltage or Petersen coil regulator.



PQModem_Stat.ecf



7.2 Setting the MODEM on the PQI-D side

The MODEM on the PQI-D side must be set in such a way that it can receive calls. The settings required for this purpose are (the AT commands for the MODEM Devolo Microlink 56 k i are used as examples):

Begin with default settings	&F
Deactivate the result codes	Q1
Ignore DTR	&D0
Echo Off	E0
Answer call after ringing three times	S0=3
End of the command line := esc	s3=27
Silent operation	L0
Save settings as Profile 0	&W0
Load Profile 0	&Y0

The whole command is thus as follows:

AT&F Q1 &D0 E0 S0=3 S3=27 L0 &W0 &Y0

Note:

It is common practice to use only upper case or lower case letters when setting up the MODEM. The use of both upper and lower case letters sometimes leads to undesired results.

If you have a different MODEM, the settings should be carried out by an expert, as even one single incorrect character could result in faulty operation of the MODEM.

7.3 Setting the Remote MODEM

Without MODEM Call-Back


Without MODEM call-back, the MODEM can remain in standard mode.

With MODEM Call-Back

If the MODEM on the PQI-D side calls back, this MODEM must also be set in such a way that it can receive calls. The same settings as described in section apply.

7.4 Settings of the “RS232Server”

In the file “RS232Server.ini”, “TELLIST” must be the specified connection to the MODEM next to the handshake procedure



Two PQI-Ds are connected in the example.

The first PQI-D is connected via a TCP/IP connection. The second one to COM 1, with MODEM; this is indicated by the entry “TELLIST” after the handshake entry RTSCTS.

In the section [TELLIST] further down in the file, you do not need to change anything.

The baud rate and COM interface can be easily set via the Interface tab.

Without MODEM Call-Back


If no MODEM call-back is required, the process is complete.

With MODEM Call-Back

With MODEM call-back, the RS232Server must be in continuous operation to recognise incoming calls from the MODEM. (See also the overview of continuous operation in section 7.2.2. Here, the setting "Autoclose=0" must be made).

7.5 Configuration of the WinPQ Software

In **PQStart**, click "Properties: station" and select the "MODEM" tab.



Select the checkbox "Use MODEM" and enter the number with which the MODEM is to be called.

If you use a telephone system and need to pre-dial 0, enter "0" before the number. The comma stands for a break of 0.5 seconds. This is required by some telephone systems. In addition, you should enter **X3** as a pre-dial command. **X3** causes the MODEM to dial immediately, and it does not wait for a dial tone.

Start one of the **WinPQ** programs to ensure that the settings are correct. We recommend the program "ID, LAN, Time", since the smallest amount of data is transferred in this case.

8. The WinPQ Management Programs in Continuous Operation


The programs **"PQManager"**, **"PQRS232Server"**, and **"PQRvReport"** (if error messages are printed out automatically) run in the background.

Usually, the program **"PQManager"** must run continuously to ensure that the database is updated continuously. In some use cases, the programs **"PQRS232Server"** and **"PQRvReport"** must also run continuously.

The programs come with a self-shutdown mechanism, since experience has shown that the system is more stable if the programs are shut down once per day in order to clear the databases interface.

They must therefore be re-started again once per day via the Windows Task Scheduler.

8.1 Windows Task Scheduler



The Task Scheduler can be found under Start / Settings / Control Panel.

8.2 The Management Programs in Continuous Operation

	Standard	MODEM call-back
PQManager	Continuous operation	Can shut itself down
PQRS232Server	Can shut itself down	Continuous operation

If error messages are to be printed out immediately:

	With immediate printout of error message	Without immediate printout of error message
PQRvReport	Continuous operation	No continuous operation


8.3 Setting PQManager to Continuous Operation:

Under the tab "PQManager" in the "PQAdmin" part of the program, set the following parameters:

RS232Start = 1

CloseEndOfDay = 3

Offline = 0



Enter the program into the Task Scheduler with a start time of 00:03.

In MODEM mode, the entry "Offline=1" should be displayed in the PQManager.

8.4 Setting the PQR232Server to Continuous Operation

Under the tab "RS232" in the "PQAdmin" part of the program, set the following parameters:

CloseEndOfDay =3
Autoclose =0

Enter the program into the Task Scheduler with a start time of 00:04.

8.5 Setting PQRvReport to Continuous Operation:

PQRvReport has the same automatic shutdown mechanisms, and thus the files have to be changed in the same way. You only need to enter the program into the Task Scheduler with a start time of 00:05.

9. Setup and parameterization – PQI-D/DA

9.1 Setup with PQ Para Express




WinPQ-ParaExpress is a small software only for changing the setup and parameters in PQI-D and PQI-DA. This software is free of charge and available on www.a-eberle.de.

All settings for the hardware could be made with this software. With online data you can check the correct connection of the device.


It is possible to start this SW directly from an USB-stick. An installation on PC is not necessary.

Please use all information from chapter 9 if you work with PQ Para Express



Com port you are using on your PC

9.2 Setup with WinPQ




Parameterization of the hardware PQI-D and PQI-DA

ID, LAN, Time	Change device name and com port settings. Each device must have a different ID in the PQ-system. The standard ID name after delivery is always "Q1"
Thresholds, connection, IO	Here the transformer factors (VT and CT ratio), the PQ event thre-

(relais, binary inputs)	sholds and the IO settings can be changed.
Measuring parameter / trigger	Thresholds for disturbance recorder and all measurement values for the permanent recorder can be changed here.
All together	All settings of ID, LAN, Time + Threshold connections + Measuring parameters can be read out or sent in one step

Recommendation: setup for different voltage levels and different hardware configurations.



In this folder you will find for each hardware version and for each voltage level a recommended setup.

- 0 U3 = device with 8 voltage inputs
- 0 I3 = device with 4 voltage + 4 current inputs

All setups are prepared according the latest version EN50160 (2010).

- 0 The factory setup for a new device with 100V voltage inputs is the setup for a typical medium voltage network *"EN50160 – 1kv-35kv"*.
- 0 The factory setup for a new device with 400V voltage inputs is the setup for a typical low voltage network *"EN50160 – 400V"*.


All parameters and thresholds can be changed at any time. With the icon "Save" different customized setups can be stored and used for all other PQI-D's in the network.

9.3 ID, LAN, Time

In this menu basic settings like device name and communication parameters can be changed.

Device name possible are „A1“ to „Z4“
Each device must have a different name in the network!

Change date and time of the hard-




Each device has two RS232 interfaces. The current used interface is yellow accentuated. (In this example COM-Port1)

With „E-LAN“, different devices from A. Eberle can be connected and communicate with a cooper line (2 lines or 4 lines possible)

9.3.1 Time synchronization


With the card "Time synchronization", special settings according the time synchronization of each device can be made. The time signal is connected with time and trigger bus (in this way there is no background program necessary)



2. Quality of the time signal (only read)
3. Summer - winter time switch (1= yes / 0= no time change from summer to winter time)
4. If the synchronizations bus is used between PQI-D´s the setting is "Master" or "Slave"
5. Setting of the time zone (Germany = GMT +1)
6. Time zone of GPS signal (f. e. GMT = 0)
7. Permitted maximum time difference.
8. Show time impulse on status LED (0=no/1=yes)
9. Time change local or external (0=local – own internal time change)
10. If a time change larger than this threshold is made, the system will generate one event.
11. In this time period (in this example 10 min) the device will not react to an external time signal.


9.3.2 ECL commands

In "ECL commands" it is possible to send short commands or small programs to the PQI-D. These programs will work parallel to the firmware of the device.



9.3.3 ELAN structure

With "ELAN structure", it is possible to see all with "E-LAN" connected devices in the network in one diagram. In this example different "REG-D" and "PQI-D" devices are connected.



9.4 Thresholds, connection, IO

In "thresholds, connection, IO" the transformer factors (VT and CT ratio), the PQ event thresholds and the IO settings can be changed. Example of PQI-DA (8x voltage inputs):

Nominal voltage (phase – phase voltage)
 The most of the trigger and PQ thresholds are related to this value

Transformer factors:
 Primary/Secondary

Picture of circuit to connect to the mains
 (f.e. V-connection, aron connection...)

9.4.1 Special parameter

In special parameter it is possible to change wrong connections of voltage and current inputs.

Example:
 Current inputs channels 5 to 8 are connected in the wrong direction. With the SW it is possible with "negative" to change the phase angle with 180°

Reference voltage channel for frequency measurement.

Here all input channels could be changed to a different input

The "10 min interval" can be changed here to 5, 10, 12, 15, 20 and 30 minutes

9.4.2 EN50160 thresholds

With this card all PQ event thresholds could be changed.


Standard setup are the limits according EN50160 (2010) for a medium voltage network.

Mains connection/transformer		Special	EN50160 threshold values	Transnastic	Analogue output	Binary input	Relay output
<input checked="" type="radio"/> Global threshold <input type="radio"/> Harmonic threshold		Limits for harmonics					
[SwellValue]							Parameters
1: HYSF: Swell hysteresis of frequency [Hz]							1.05
2: TPNL: Frequency lower threshold narrow tolerance (49.5 Hz)							49.5
3: TPNU: Upper threshold narrow tolerance (50.5 Hz)							50.5
4: TFWL: Lower threshold wide tolerance (47.0 Hz)							47.0
5: TFWU: Upper threshold wide tolerance (52.0 Hz)							52.0
6: PFN: Permissible frequency infractions narrow tolerance (0,5%)							0.5
7: FC: Middle frequency of ripple control voltage [Hz]							168.0
8: Limits for flicker, dips, swells, frequency, unbalance							9.0
9: Limits for flicker, dips, swells, frequency, unbalance							0.5
10: Limits for flicker, dips, swells, frequency, unbalance							1.0
11: NSIG: Admissible number of days with to often violation of the 3s-ripple control voltage/year							10.0
12: HYSPI: Hysteresis of half period values (1.0%)							1.0
13: TVS: Fast voltage change/swell (106.0 %)							106.0
14: TVD: Fast voltage change/dp (94.0 %)							94.0
15: NFVCD: Permissible number per day (10)							10
16: NFVY: Permissible number per year (3650)							3650
17: TDD: Threshold deep dp (90.0 %)							85.0
18: NDOY: Permissible number per year (100)							1000
19: TSI: Threshold voltage interruption (40.0 %)							10.0
20: DSI: Time criterion short/long (Sec.)							180
21: NSIY: Permissible number of short interruptions per year (30)							200
22: NLIY: Permissible number of long interruptions per year (10)							50
23: TOV: Threshold temporary overvoltage (170.0 %)							200.0
24: NOVY: Permissible number per year (10)							10
25: TSVCL: Slow voltage change lower threshold (90.0 %)							90.0
26: TSVCU: Upper threshold (110.0 %)							110.0
27: PSVC: Permissible frequency per week (5.0%)							5.0
28: TUV: Threshold voltage unbalance (2.0 %)							3.0
29: FUV: Permissible frequency per year (5.0 %)							5.0
30: TTHD: Threshold total harmonic distortion (8.0 %)							8.0
31: FHD: THD+Harmonic Permissible frequency per week(5.0 %)							5.0
32: TPST: Threshold flicker short term (1.0)							1.0
33: TPLT: Threshold flicker long term (1.0)							1.0

9.4.3 Transnestic

The function “Transnestic” can be used to analyze the kind and direction of disturbances.

A detailed description of this function you will find in the user manual WinPQ.



Possible messages from the system:

- TRANSNOSTIC: Short circuit phase-to-earth own mains (behind measurement point) [TN_K1P]
- TRANSNOSTIC: Short circuit phase-to-phase own mains (behind measurement point) [TN_K2P]
- TRANSNOSTIC: 3-phase short circuit own mains (behind measurement point) [TN_K3P]
- TRANSNOSTIC: Short circuit front of measurement point [TN_KIM]
- TRANSNOSTIC: Peak own mains (behind measurement point) [TN_PEX]
- TRANSNOSTIC: Peak front of measurement point [TN_PIM]

9.4.4 Option M94/M95 – analogue output

If the hardware option M94 or M95 is installed in the PQI-D it is possible to deliver any measurement value with an 0 – 20mA output signal.

Mains connection/transformer		Special	EN50160 threshold values	Transnestic	Analogue output	Binary input	Relay output	LED display
Analogue I/O								
[AnaIO]	Allocation		Adjustment time					
CHANNEL; [1]	▲	8576=P1						
CHANNEL; [2]	▲	8577=P2						
CHANNEL; [3]	▲	8578=P3						
CHANNEL; [4]	▲	0=Off						
CHANNEL; [5]	▲	0=Off						
CHANNEL; [6]	▲	0=Off						
CHANNEL; [7]	▲	0=Off						
CHANNEL; [8]	▲	0=Off						

Allocation of measurement values

Example:

P L1 = cannel 1

P L2 = channel 2

Transfer function						
[AnaFkt]	X0 (Input)	Y0 (Output/-1.2...+1.2)	X1 (Input)	Y1 (Output/-1.2...+1.2)	X2 (Input)	Y2 (Output/-1.2...+1.2)
CHANNEL; [1]	-200000	-1	1	1	200000	1
CHANNEL; [2]	0	0	1	1	1.05	1.05
CHANNEL; [3]	0	0	1	1	1.05	1.05
CHANNEL; [4]	0	0	1	1	1.05	1.05
CHANNEL; [5]	0	0	1	1	1.05	1.05
CHANNEL; [6]	0	0	1	1	1.05	1.05
CHANNEL; [7]	0	0	1	1	1.05	1.05
CHANNEL; [8]	0	0	1	1	1.05	1.05

X0 =	Lower value (e. -200 000 = -200kW)
Y0 =	Lower output signal PQI-D (f.e. -1 = -20mA)
X1; Y1 =	Central value (input necessary f.e. X1=0 / Y1=0)
X2 =	Upper value (f.e. 200 000 = +200kW)
Y2 =	Upper output value PQI-D (f.e. 1 = 20mA)

9.4.5 Option M97/M98 analogue inputs

The options M97 and M98, provides four additional analogue inputs. Is is possible to connect voltage signals from 0 to 10V or current signals from -20mA...0...+20mA.

Example:

Channel 2: radiation (W/qm) – input 4 – 20mA = output in WinPQ: 0 – 1600 W/qm

The value = 1 is equivalent to 20mA (or 10V)

Allocation	Symbol	Unit of measure	Input signal normalized	Transfer function	Lower threshold	Upper threshold
CHANNEL [1]		V	0	▲ OFF	-2.0	+2.0
CHANNEL [2]		W/qm	0	▲ 3 point	-2.0	+2.0
CHANNEL [3]		°C	0	▲ OFF	-2.0	+2.0
CHANNEL [4]		mA	0	▲ OFF	-2.0	+2.0

Limit for alarming, if the analogue input signal goes over or under lower or upper threshold

3-point-characteristic	P0 (normalized input value)	P0 (measured value)	P1 (normalized input value)	P1 (measured value)			
CHANNEL [1]	0	0	1	1	1.05	0	0.628
CHANNEL [2]	0	0	0.2	0	1	1600	0.628
CHANNEL [3]	0	0	1	1	1.05	0	0.628
CHANNEL [4]	0	0	1	1	1.05	0	0.628

The analogue inputs can be recorded in these data classes:

200ms; 3 sec; 10 min; 2 h interval.

Additional there are 200ms extreme values available in 3 sec; 10 min; 2 h interval

Overview | 0,2-second average | 3-second-average | 10-minute-average/extreme | 2-hour average | Daily statistics | Trigger thresholds | External-trigger-out | Recorder A | Recorder B | Recorder C | Recorder S | Events

Average and spectral values of important mains parameters:

Recording points: 0 | Recording mode: circular | Send | Menu

[C3s] ChNum=4	Channel ID (measured value)
CHN_1	[14848]: AI_1/Analog input 1 [Fit]
CHN_2	[14849]: AI_2/Analog input 2 [Fit]
CHN_3	[14850]: AI_3/Analog input 3 [Fit]
CHN_4	[14851]: AI_4/Analog input 4 [Fit]
CHN_5	[0]: Off
CHN_6	[0]: Off
CHN_7	[0]: Off
CHN_8	[0]: Off

Frequency | Voltage | Current | Power | Direction harmonic active power | Phase U1E-n - 11-n (n=2..40) | Phase U2E-n - 12-n (n=2..40) | Phase U3E-n - 13-n (n=2..40) | Analog input | Analog extreme values | Voltage harmonics | Current harmonics

[AE_35] 4	Selection;
14848: Analog input 1 [-]	✓ AI_1
14849: Analog input 2 [-]	✓ AI_2
14850: Analog input 3 [-]	✓ AI_3
14851: Analog input 4 [-]	✓ AI_4

9.4.6 Binary inputs

On this card it is possible to change the name and the status of all binary inputs. The binary inputs could be inverted (no signal = 1 / signal = 0) or set permanent high or low. If the hardware option M96 is installed the sampling frequency of all binary inputs is 10.24 kHz, we suggest to use the debouncing filter. With M00 the sampling interval of binary inputs is 4 milliseconds.

Mains connection/transformer Special EN50160 threshold values Transnoscic Analogue output Binary input Relay output LED display				
Statistics: Debounce cycle: <input type="text" value="5"/>				
Binary in				
[BinIN]	Name	Logic state: Voltage on input	Debounce [M96] falling edge	Debounce [M96] rising edge
CHANNEL; [1]	Protection 1	▲ inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [2]	Protection 2	▲ High	▲ With debouncing	▲ Without debouncing
CHANNEL; [3]	Protection 3	▲ Low	▲ With debouncing	▲ Without debouncing
CHANNEL; [4]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [5]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [6]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [7]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [8]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [9]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [10]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [11]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [12]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [13]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [14]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [15]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing
CHANNEL; [16]	Name	▲ not inverted	▲ With debouncing	▲ Without debouncing

SQL Help

Tab: SQL | Tab: User | Tab: RS232 | Tab: INU setup

Input registration code

Display/change of licence code

Folder user setup
C:\Programme\WinPQ\

PQStart desktop

User setup

Name of company
Stadtwerke Ahorn

PDF files folder
C:\Programme\WinPQ\TMP\

Other setup
 Record binary input
 Log file for all programs
 Program-alert-beeper OFF

Save settings | Language resources | Font


Select SQL connections

- coburg
- PQAdmin
- PQBox
- PQDemo
- PQManager
- PQSys
- PQVisu

Select PQStart functions


- Recorder
- PQ events
- PQ overview
- Measuring data
- EN reports
- Online data
- Read out data
- Thresholds/connection
- 1xV Threshold/connection
- Measuring parameter/trigger
- 1xV Measuring parameter/trigger
- Compact
- Mobile profile
- CP Threshold/Connections
- CP Measuring parameter/Trigger
- CP Calculation setup
- CP Online data
- Reg-D Basic functions
- Reg-D parallel operation
- Analogue/binary IO
- Trafo monitoring
- Add-on devices
- ID, LAN, Time..
- Start: comm.exe
- Start: PQAdmin
- Start: PQMail
- Demo: Guide

To display the binary channels together with the recorders the option "record binary inputs" must be activated.



9.4.7 Messages on Relays and LED's

Alarms or messages could be reported on any relay or LED. The status relay is always used for the “watch dog function” of the PQI-D. The function of the status relay is inverted. Relay is always on and opened if the PQI-D has an error.




With a pull down menu in “conditions1 ...”, it is possible to select from 142 trigger signals. Up to 32 conditions could be “or linked”

- 121=Trigger signal: wave shape U1 [TrgET1]
- 122=Trigger signal: wave shape U2 [TrgET2]
- 123=Trigger signal: wave shape U3 [TrgET3]
- 124=Trigger signal: wave shape U12 [TrgET12]
- 125=Trigger signal: wave shape U23 [TrgET23]
- 126=Trigger signal: wave shape U31 [TrgET31]
- 127=Trigger signal: wave shape UNE [TrgETN]
- 128=Trigger signal: lower threshold half period voltage positive sequence system [TrgLPS]
- 129=Trigger signal: upper threshold half period voltage Positive sequence system [TrgUPS]
- 130=Trigger signal: upper threshold half period voltage negative sequence system [TrgUNS]
- 131=Trigger signal: upper threshold half period voltage zero system [TrgUZS]
- 132=Trigger signal: lower threshold half period-current I1 [TrgL1_I]
- 133=Trigger signal: lower threshold half period-current I2 [TrgL2_I]
- 134=Trigger signal: lower threshold half period-current I3 [TrgL3_I]
- 135=Trigger signal: upper threshold half period-current I1 [TrgUT1_I]
- 136=Trigger signal: upper threshold half period-current I2 [TrgUT2_I]
- 137=Trigger signal: upper threshold half period-current I3 [TrgUT3_I]
- 138=Trigger signal: upper threshold half period-current IN [TrgUTN_I]
- 139=Trigger signal: half period-current jump I1 [TrgST1_I]
- 140=Trigger signal: half period-current jump I2 [TrgST2_I]
- 141=Trigger signal: half period-current jump I3 [TrgST3_I]
- 142=Trigger signal: half period-current jump IN [TrgSTN_I]

9.5 Measuring parameter / trigger

In this menu the highest number of parameters are available. All recorders (oscilloscope, 10ms rms, ripple control) and all parameters for permanent measurement can be changed in this menu. We suggest to use one of our standard setup files for parameterization of PQI-D´s



Control functions:

- Start/Stop PQ event evaluation
- Initialisation statistics
- Controls evaluation (start and stop with BIN inputs)
- Controls disturbance recorder
- Event recording mode

Recorder triggered from software

Memory allocation:

- Orange: data class is not activated
- Green: memory reserved and empty
- Red: memory filled with data

Clear memory of each data class

Online-Panel:

- 3 sec values, events
- variable column count
- variable column width
- Vector diagram

Online visualization					
C3s ID = [14.03.2008 11:31:03.9900] RR=14 ERR=0 NI=196798 AI=196790					
3-sec average EN 50160 events Vector diagram Direction harmonic power					
F	=	0,000 Hz	U31	=	0,0 V
U1E	=	0,0 V	THD12	=	0,000 %
U2E	=	0,0 V	THD23	=	0,000 %
U3E	=	0,0 V	THD31	=	0,000 %
UNE	=	0,0 V	U12H5	=	0,000 %
U12	=	0,0 V	U12H7	=	0,000 %
			U23H7		
			U31H5		
			U31H7		
			I1		
			I2		
			I3		

RecA/B disturbance recorder:

- The mode "Linear" (use of 48MB additional memory on DSP processor) has to be selected (hatched bar background in memory overview)
It is not possible to see the background memory (48MB) in this overview picture.

Permanent data (3 sec; 10min, 2h) and events:

- These recorder data classes are working with an circular memory (first in first out)

9.5.1 Status of LED's, relays and binary inputs



This display shows the status of all LED's, relays and binary inputs.

These variants are possible:

	Channel is not active		Channel is active
	Channel is fixed to not active		Channel is fixed to active

9.5.2 Online panel

With the online panel it's possible to check the correct connection of voltage and current inputs.

Overview | Online graphic | Offline table | Memory allocation


Online visualization

Menu | Stop

3-second-average | Vector diagram | Direction of harmonic load

Mains: F=49,989 Hz P=-272,461 W S=1,422 kVA Q=-1,395 kVar	Voltage: U1E=237,716 V U2E=237,421 V U3E=233,667 V UNE=0,145 V U12=409,556 V U23=409,403 V U31=408,665 V	Current: I1=1,539 A I2=1,346 A I3=1,645 A I0=2,278 A IM=-1,510 A	Power: P1=93,108 W P2=47,015 W P3=132,337 W S1=365,735 VA S2=319,581 VA S3=384,311 VA Q1=353,685 Var Q2=316,104 Var Q3=360,807 Var	V/C-THD: THD1E=1,689 % THD2E=1,711 % THD3E=1,784 % THD1=97,446 % THD2=95,242 % THD3=143,900 %	Angle: PHI1=-121,658 ° PHI2=106,349 ° PHI3=-144,779 °
--	--	--	--	--	---


9.5.3 Vector diagram



9.5.4 Parameterization of continues classes

0,2-Sek.-Mittel | 3-Sek.-Mittel | 10-Min.-Mittel/Extrem | 2-Std.-Mittel

On the card "10min average/extreme", up to 2000 different parameters available for permanent recording. The maximum number of parameters is limited to 1024 parameters. The recorder time in the circular memory depends on the number of different measurement values.



Recording time of permanent data (Example: 450 x 10min)

Display the recording time of circular memory (Example: 3 days and 3 hours)

Channel mapping:
Here all selected parameters are listed (max 1024 possible)

[C10m]	ChNum=55	Channel ID (measured value)
CHN_1		[384]: F/Line frequency [FLT]
CHN_2		[1152]: U1E/RMS value of u1E [FLT]
CHN_3		[1153]: U2E/RMS value of u2E [FLT]
CHN_4		[1154]: U3E/RMS value of u3E [FLT]
CHN_5		[1155]: UNE/RMS value of u0E [FLT]
CHN_6		[1156]: U12/RMS value of u12 [FLT]
CHN_7		[1157]: U23/RMS value of U23 [FLT]
CHN_8		[1158]: U31/RMS value of u31 [FLT]
CHN_9		[1163]: THD12/Total harmonic distortion of u12 [FLT]
CHN_10		[1164]: THD23/Total harmonic distortion of U23 [FLT]
CHN_11		[1165]: THD31/Total harmonic distortion of u31 [FLT]

Pre selection of measuring quantities:
The registers Frequency, Voltage, Current etc. serves for the pre selection of the measuring quantities. The registers (physically sorted) allow a faster finding of the desired measuring quantities.

The icon „Send“, transfers all setup changes of all cards to the hardware PQI-D

The screenshot shows the PQPara.EXE software interface. The main window title is "[TPQIPanOnPanel] C3s ID= [14.03.2008 11:54:22.4870] RR=469 ERR=0 NI=197264 AI=196790". The interface is divided into several sections:

- Left Panel:** A tree view under "PARAMETER" showing "PQID1" expanded to "Q5: PQI-D [PQI-D*/5.0.01/3]". Below it are "PQID2" and "MODEM", and a list of "OFFLINE" channels (OFFLINE_U1 to OFFLINE_I3) and "PQID".
- Top Panel:** Navigation tabs for "Overview", "0.2-sec average", "3-sec average", "10-min average/extreme" (selected), "2-hour average", "Daily statistics", "Trigger thresholds", and "Extern-trigger-out". Below these are "Recording points: 450", "Recording mode: Circular", and "155/1112 kB [3d 03:00:00]".
- Channel List Table:** A table with columns "ChNum=55" and "Channel ID (measured value)".

ChNum	Channel ID (measured value)
CHN_1	[384]: F/Line frequency [FLT]
CHN_2	[1152]: U1E/RMS value of u1E [FLT]
CHN_3	[1153]: U2E/RMS value of U2E [FLT]
CHN_4	[1154]: U3E/RMS value of u3E [FLT]
CHN_5	[1155]: UNE/RMS value of u0E [FLT]
CHN_6	[1156]: U12/RMS value of u12 [FLT]
CHN_7	[1157]: U23/RMS value of U23 [FLT]
CHN_8	[1158]: U31/RMS value of u31 [FLT]
CHN_9	[1163]: THD12/Total harmonic distortion of u12 [FLT]
CHN_10	[1164]: THD23/Total harmonic distortion of U23 [FLT]
CHN_11	[1165]: THD31/Total harmonic distortion of u31 [FLT]
- Parameter Selection Table:** A table with columns "Frequency" and "Selection;".

Frequency	Selection;
[I_10M] 29	
8064: RMS value of i1 [A]	<input checked="" type="checkbox"/> I1
8065: RMS value of I2 [A]	<input checked="" type="checkbox"/> I2
8066: RMS value of i3 [A]	<input checked="" type="checkbox"/> I3
8067: RMS value of iS/N [A]	<input type="checkbox"/> IO
8068: RMS average value of I1, I3, I3 [A]	<input type="checkbox"/> IM
8069: Total harmonic distortion of i1 [%]	<input checked="" type="checkbox"/> THD1
8070: Total harmonic distortion of I2 [%]	<input checked="" type="checkbox"/> THD2
8071: Total harmonic distortion of i3 [%]	<input checked="" type="checkbox"/> THD3
8072: Total harmonic distortion of iS/N [%]	<input type="checkbox"/> THDN
8073: Total harmonic current von i1 [A]	<input type="checkbox"/> THC1
8074: Total harmonic current von I2 [A]	<input type="checkbox"/> THC2
- Bottom Panel:** A toolbar with "Receive", "Open", "Send", "Save", "Print", and "Manual" buttons. The status bar shows "CON: Joerg-Vista-PC/1701", "Q5: PQI-D [PQI-D*/5.0.01/3]", "Q5: FREAD. pqi.2 5341184 8", and "PQID1=localhost:1701".

9.5.5 Parameterisation of disturbance recorder

All thresholds for the disturbance recorder (oscilloscope & 10ms rms recorder) can be changed on card "Trigger thresholds".

Overview	0.2-sec average	3-sec average	10-min average/extreme	2-hour average	Daily statistics	Trigger thresholds	Extern-trigger-out	Recorder A	Recorder B	Recorder C	Recorder S	Events
Control: recorder/statistics (bus 1)												
[Trigger Tresh]											Values:	
1: Trigger signal dwell time [s]												1
2: Frequency hysteresis [Hz]												0.05
3: Frequency upper threshold [Hz]												50.50
4: Frequency lower threshold [Hz]												49.50
5: Frequency jump [Hz/s]												0.50
6: Hysteresis for 1/2-period-voltage [%]												
7: Upper threshold [%], line-to-earth-voltage												
8: Lower threshold, line-to-earth-voltage												
9: RMS jump threshold [%], line-to-earth-voltage												
10: Phase jump threshold [°], line-to-earth-voltage												
11: Upper threshold [%], NE voltage												
12: RMS jump threshold [%], NE voltage												
13: Upper threshold [%], line-to-line-voltage												
14: Lower threshold [%], line-to-line -Voltage												
15: RMS jump threshold [%], line-to-line -Voltage												
16: Threshold wave shape trigger [%], line-to-earth-voltage												
17: Threshold wave shape trigger [%], line-to-line-voltage												
18: Threshold wave shape trigger [%], NE voltage												
19: Upper threshold positive sequence system [%]												
20: Lower threshold positive sequence system [%]												
21: Upper threshold negative sequence system [%]												
22: Upper threshold zero sequence system [%]												
23: Hysteresis for current RMS values [%]												
24: Upper threshold [%], phase current												
25: Lower threshold [%], phase current												0.00
26: RMS jump threshold [%], phase current												20.00
27: Upper threshold [%], sum current												50.00
28: RMS jump threshold [%], sum current												20.00
29: FC: Middle frequency of ripple control voltage [Hz]												168.0
30: Triggerschwelle Recorder 5 [%], bus 1												1

Thresholds:

- Frequency
- Voltage line-to-earth (lower + upper)
- Voltage line-to-line (lower + upper)
- RMS jump
- NE voltage
- Phase jump
- Wave shape trigger
- Balanced components
- Trigger by Current thresholds
- Fast current RMS change
- Ripple control voltage

9.5.6 Parameterisation for disturbance recorder

With the cards "Recorder A" and "Recorder B" the recorder length, the pre recorder time can be changed.

The screenshot shows the PQPara software interface with several key sections:


- Overview:** Shows recording parameters for Recorder B (10-ms-values), including recording points (10), recording mode (Linear), and recording time (332/1112 kB).
- [RecB] 17:** A table of selected parameters for recording, such as I1, I3, I5, I12, I13, I15, I18, active power, reactive power, apparent power, frequency, and frequency gradient.
- [RecBSetup]:** Recorder parameters including:
 - 1> Record length (sample points): 300
 - 2> Pre-trigger (sample points): 100
 - 3> Re-trigger (sample points)
 - 4> Maximum recorder number per sequence
- Trigger mask:** A table of trigger conditions (1-5) with checkboxes for various thresholds like U1E, U2E, U3E, U12, U23.

Annotations provide further details:

- Direct selection of recorder values:** (f.e. 10ms recorder) Voltage, current, real power, frequency...
- Recorder parameters:**
 - recorder length
 - pre trigger time
 - re trigger time
 - max. recorder per sequence
- Trigger conditions can be activated and deactivated here:**
 - Fast change of the RMS of voltage
 - Phase jumps
 - Trigger by Current thresholds
 - Fast current RMS change
 - Binary input (falling or rising edge)

9.5.7 Parameterization of harmonic recorder RecC

If the values of any harmonic or the THD exceed the thresholds, a list of the frequency spectra from voltage and current are stored. The number of harmonics up to the 50th can be selected.



The screenshot shows the configuration window for Recorder C. The main configuration area includes the following settings:

- 10-min average/extreme | 2-hour average | Daily statistics | Trigger thresholds | Extern-trigger-out | Recorder A | Recorder B | Recorder C
- Recorder C (10-min values of 2..40 harmonic in the case of a limit value infraction)
- Recording points: 10 | Recording mode: Circular | Send | Menu | 2/1112 kB

The [RecCSetup] table is configured as follows:

[RecCSetup]	Values:
1> First harmonic	2
2> Number harmonics	24

The Trigger mask section is configured as follows:


[TriggerC1]	Recorder C
Condition; [1]	<input checked="" type="checkbox"/> Deviation THD U1E
Condition; [2]	<input checked="" type="checkbox"/> Deviation THD U2E
Condition; [3]	<input checked="" type="checkbox"/> Deviation THD U3E
Condition; [4]	<input checked="" type="checkbox"/> Deviation THD U12
Condition; [5]	<input checked="" type="checkbox"/> Deviation THD U23
Condition; [6]	<input checked="" type="checkbox"/> Deviation THD U31

Callout boxes provide additional information:


- Number of harmonics: In this example: 2nd up to 25th harmonic
- Trigger conditions to start a harmonic record

9.5.8 Parameterisation of RecS

The “recorder S” is designed to record the ripple signal voltage in the network.




The frequency of the ripple voltage signal can be changed on card “Trigger thresholds”. In our example the frequency is adjusted to 168Hz. The frequency can be selected from 5Hz to 2.500Hz.



9.5.9 Parameterization of power quality events

According to European Standard EN50160, all measurement values should be evaluated phase-earth in low-voltage networks and phase-phase in medium-voltage networks. In our standard setup for a MV network only phase to phase events are recorded.



10. Time synchronization

Select the device to which the clock is to be connected. A COM2 interface on the rear side of the module rack can be used.

10.1 Time synchronisation with DCF77 time clock


A DCF-77 clock can be connected to all devices of the **REGSys** family with a serial interface. The clock then receives the long-wave radio signal from the German atomic clock in Darmstadt. Some settings need to be made on the device in order to synchronise **REGSys** devices with this time.

Connection COM1 (front):

The DCF77 modul can be connected directly to the interface COM1

Connection COM2

At the terminal COM2 these signals are available: TXD[b20], RXD[b22], RTS[z20], CTS[z22] and GND[b24]. Connection with the adapter cable shown in the picture



10.2 Time synchronisation with GPS time clock

The GPS time clock (NIS GPS clock) can be connect with the RS232 interface or directly to the time bus (RS485). The connection to the time bus is more precise and recommended. The clock delivered a converted DCF77 signal to the output:

At the terminals DCF-EA+ and DCF-EA- a DCF- signal with RS485 levels will be delivered.


GPS NIS clock	PQI-DA
DCF-EA+	„A“ at terminal X6, no. 47
DCF-EA-	„B“ at terminal X6, no. 48
GND	„GND“ at terminal X6, no. 50

Please install the termination of the bus like it is suggested in the PQI-D or PQI-DA manual.

For the GPS time clock there is also a manual available

10.3 Interface settings for time clock connected to RS232

Start the program “ID, LAN, Time”.



Make sure that you have loaded the correct device (to which the clock is to be connected). Set the selected interface (COM2 in the figure above) to mode “DCF77”.

All other fields on this COM interface are ignored. Click on the "Set" button under this setting. The interface is now set to receive a DCF-77 signal. The connection of the time clock to the RS232 is much slower than the connection directly to the time bus (RS485) of the analyzer.

10.4 Interface settings for the GPS clock connected at the time bus

If the GPS time clock is connected directly to the time bus (RS485), this clock will be the time master and all other devices connected to the bus are time slaves. The time difference between different devices is < 10ms. You have to change the setting "Slave" in WinPQ under ID/LAN/time



identification data: Communication <input checked="" type="radio"/> Time synchronization ECL commands E-LAN structure	
Time synchronization	
Date/Time:	
03.03.2011	16:22:45
[DCFSync]	
Parameters	
1: DCF: quality of receive signal	0
2: Summer-/Wintertime change over (DST) 0=disabled, 1=enabled	▲ 0: Disabled
3: DCF-operation mode, 0=Single, 1=Slave, 2=Master	▲ 1: Slave
4: Time zone of the device in 0.25-h raster (e.g. 1.0 in case of Germany)	▼
5: Time zone of DCF-time code in 0.25-h raster (e.g. 0.5 or 1.0)	1.0
6: Maximum time deviation DCF-edge of rated value [s]	1.0
7: Release of DCF-time-pulse-display on status LED	▲ 0: Off
8: DST-Operation mode, 0=local, 1=external	▲ 0: local
9: Time tolerance [s] for message TIMESET	▼
	1.0

10.5 Setting up the synchronization with E-LAN connection

If several measuring devices are connected with E-LAN communication and have to be synchronised, a background program must be installed on the device connected to the time clock.

(Time synchronisation could be also a PC or GPS clock)

The fastest way to synchronise different power quality devices is the connection with the time & trigger bus. With E-LAN there could be a time difference of 200ms between different devices.



In the same program "ID, LAN, Time", switch to the tab "ECL commands".

Initiate the program "PQDcfTime.ed" by clicking "Load". In the figure, this has already been done.

The first two rows (starting with the character #) are comments.

The first command is in line 3: "DCFSTATUS".

1. Check to ensure that the clock emits a signal. Click line 3 with the command DCFSTATUS. Then click the button "Step". If the signal from the clock is received without errors, a text of this type will appear: **DCF-Time : 13:46:15 [1m]** Check to see if the time of day is indicated correctly.

If a text of this type is displayed:

DCF-Time : ??:?:?:00 [5579m]

Adaption : --:--:--

The clock does not emit a correct signal.

Possible reasons might range from a clock that is not switched on to cable problems or weak reception. The signal is emitted from Darmstadt, the antenna should therefore point in this direction. Continue only when the time is displayed correctly.


Note: It can take up to 5 minutes until the initial synchronisation takes place.

2. Displaying of the clock times of all REGSys devices in the ELAN. The command `all,time//&` can be skipped here. It shows a list of all devices with the respective time. This will be useful later, when you want to check whether all devices indicate the same time.
3. Check to see if row 30 of the background program is free. Click the cell with the entry HList* and then "Step". A list with the H-program rows pops up. Scroll down until you can see the entry "H30 = ...". If it is empty, i.e. H 30 = ' ', you can use H30 and continue with the next step. If it is not empty, you should contact eberle to obtain a solution.
4. Setting up the background program to permit time synchronisation. Click the cell with the entry `H 30='IF 3:0:15,all-,zeit//=xhx:x x.x.x'` and then "Step". The command is repeated in response.


Time synchronisation has now been set up. Every day, all REGSys devices in the ELAN are set to the DCF time at 03:00:15.

11. Firmware update PQI-D and PQI-DA

It is possible to see the actual version of the hardware PQI-D or PQI-DA and the suitable firmware using the software WinPQ / PQ Para



With "device information", you will see all the information about the hardware and firmware version of the connected device.



A firmware update can only be done if the device is running in “urloader mode”.

Please press the reset button of the PQI-D /-DA for more than 5 seconds.

If the device is running in “urloader mode” you can see this in the following indication:


PQI-DA:

- Service LED = green
- Fault LED = red




PQI-D:


- Service LED & notification LED = green
- Fault-LED = red



To send the firmware update to the device, use the program "Comm.exe" in WinPQ.



Change the parameter of your COM settings suitable to your PC.



Example of the COM settings:


Interface of the PC = COM 11

Flow control


Baudrate = 115.000

- If the device is not in "urloader mode", and if the settings of the interface are correct the devices will answer with its name (i. e. Q4)

- If the device is in "unloader mode", you can ask with the command "ver", the firmware version of the device.




If the version of the PQI-D/DA is old, it's necessary to update the file "Boot loader" also.




For the firmware 4.xx and 5.xx a boot loader 2.xx is necessary.

With the command "Firmware senden mit Reset", you can send the new firmware to the device. The device will make a reset after the file transfer is finished.




The blue bar graph shows the status of the firmware transfer.




12. Setting of the PQ-Mail

With the program „PQMail.exe“ it is possible to send messages or PDF-documents automatically to different email-groups. This function only works if the program „PQRvReport“, works permanently.



Open the „Setup mail-Program“.




1. The settings can be checked Via „Test Mail“. A test- mail will be sent. Via „Attachment“, the mail gets an addition. (PDF)
2. If only one group of e-mail receiver is used, this group can later be selected as „Default“. The settings have to be saved before. (**Save setup**)
3. „**Additional receiver**“, gives the alternatives to add more Email receivers (groups).
4. The storage place for PDF files can be selected (Red circle).

13. Automatically print or e-mail order

To generate PDF documents and email reports automatically, it is necessary the **PQRvReport-Programm** is operating permanent. This program should not be closed. (Continuous operation is described in chapter 8)

To use the automatically operation, this program must be opened in Windows Explorer and not by PQ Start surface.


If some settings would be changed, the „Auto-Report“, must be disabled. After that the function must be enabled. For this moment the report function operates automatically




13.1 Automatically generated disturbance reports

To generate self acting disturbance reports, choose the template "RECORDER ABC"

With **Automate template** it is possible to generate PDF- documents, email-reports or reports via printer automatically. This reports will be activated by new disturbances.






The list in with the program „PQRvReport“ saves PDF documents could be changed in the menu point „PDF output folder“ It's possible to generate a new folder

13.2 Automatic power quality reports

In contradiction to disturbance- reports, norm- reports will be generated by adjusted time-period and not after an event. Norm- reports can be generated per day, week or year. The example below shows: The „EN50160“, report will be started every Monday on 8:00 o'clock and sends it to the selected printer. The stations must be enabled.




If the automatic report function should be disabled, the time has to be 0:00 o'clock.

13.3 Mail dispatch of automatic reports


Is there only one E-Mail group existing, these group will called „Default“.

The example bellow shows the settings of automatic generation from the Recorder-B. The device Q1 is selected and the mail receiver are those under Default setting.



To send disturbance or norm- reports to different groups of mail receivers, it is necessary use the „Mail- Setup“.

The task „other parameter“



A. Eberle GmbH & Co. KG

Aalener Str. 30/32
D-90441 Nuremberg

Tel.: +49 (0) 911 / 62 81 08-0

Fax: +49 (0) 911 / 62 81 08 96

E-Mail: info@a-eberle.de

<http://www.a-eberle.de>

Software - Version:
