

SECUTEST BASE, BASE10 and XTRA

Test Instruments for Measuring Electrical Safety of Devices per VDE 0701-0702, DIN EN 62353 and DIN EN 60974-43

3-349-753-03 3/11.13

- 8 pre-set test sequences per standard to perform standardized Tests for electrical, medical and welding instruments one freely configurable test sequence for special duties
- Automatic evaluation of executed test sequences
 in consideration of measuring uncertainty
- Pioneering operating concept with double rotary switch, direct selection keys and softkeys
- Revolutionary data management and storage concept for automated test sequences and single measurements with memory for up to 50,000 data records
- Automatic DUT connection and protection class detection
- Voltage measurement up to 300 V for testing SELV/PELV circuits
- Measurement of leakage current with a bandwidth
 of up to 1 MHz
- Compact, impact resistant housing with integrated rubber protector



Features

- State-of-the-art, multi-channel measuring technology for fast measured value acquisition. Measured values are acquired via 16 channels simultaneously, so that all measured values are available at the same time.
- Active (direct) measurement of leakage current from the application part via the test probe with an option for selecting the phase angle to mains power.
- Quick export of the database
- The test list view provides an outline of all executed tests along with their results and respective evaluations.
- Multiple measurement is a user-optimized measuring process which allows for convenient recording of several measuring points.
- Quick execution of the most important functions via "direct selection lists"
- Direct printout of test reports or test report management with free ETC software

Standards for the Use of SECUTEST BASE, BASE10 and XTRA Test Instruments

		Testing after Repairs / Periodic Testing					
DUTs to be tested in accordance with the following standards	DIN VDE 0701-0702	IEC 62353:2007 DIN EN 62353:2008 (VDE 0751-1)	DIN EN 60974-4 VDE 0544-4				
Electric devices	•						
Work devices	•						
Mains operated electronic devices	•						
Hand-held electric tools	•						
Extension cords	•						
Household appliances	•						
Data processing devices	•						
Electrical medical devices, application parts		•					
Welding units	•		•				

Overview of Features Included with SECUTEST Base, Base10 and XTRA Test Instruments

Switch Setting	Meas. Variant	Measuring Function, Test Current/Voltage					
-	easuremen		switch level: green				
-	ments at v						
RPF	inonito at v	R _{PF}	Protective conductor resistance				
			Protective conductor current (200 mA) SECUTEST BASE10/XTRA: 10 A ¹				
Riso	PC I	R _{ISO}	Insulation resistance				
	PC II	UISO	Test voltage				
Measure	ments at D	UTs with I	ine voltage				
IPE		I _{PE} ~	Protective conductor current, RMS value				
	DIR	I _{PE~}	AC component				
	DIF ELC	I _{PF=}	DC component				
	LLU	UIN	Test voltage				
в		I _B ~	Touch current, RMS value				
	DIR	I _{B~}	AC component				
	DIF ELC	I _{B=}	DC component				
	LLO	UIN	Test voltage				
lg		I _{G∼}	Device leakage current, RMS value				
	DIR	I _{G~}	AC component				
	DIF ELC	I _{G=}	DC component				
	LLO	U _{LN}	Test voltage				
IA	DIR	I _{A~}	Leakage current from the application part				
	ELC	U _A	Test voltage				
IP		$I_{P\simeq}$	Patient leakage current, RMS value				
	DIR with	I _{P~}	AC component				
	probe	$I_{P=}$	DC component				
		U _{LN}	Test voltage				
U		U_{\sim}	Probe voltage, RMS				
		U~	Alternating voltage component				
		U_	Direct voltage component				
ta		ta	PRCD time to trip for 30 mA PRCDs				
		U _{LN}	Line voltage at the test socket				
Р		Function	n test at the test socket				
		I	Current between L and N				
		U	Voltage between L and N				
		f	Frequency				
		Р	Active power				
		S	Apparent power				
		PF	Power factor				
Probe m	easuring fu	inctions					
EL1		Extension	cords with EL1 adapter: , short-circuit, polarity (wire reversal)				
EXTRA		Reserved for expansion during the course of software update:					

Key

DIR = direct measurement,

DIF = differential current measurement,

ALT = alternative measurement (equivalent leakage current measurement)

Switch Setting	Meas. Variant	Measuring Function, Test Current/Voltage					
Automated test sequences, rotary switch level: orange							
Permanently configured test sequences							
A1		VDE 0701-0702, passive measuring method, test socket					
A2		VDE 0701-0702, active measurement type, test socket					
A3		VDE 0701-0702, parameters configuration for EDP (active)					
A4		EN 62353 (VDE 0751), passive measurement type					
A5		EN 62353 (VDE 0751), active measurement type					
A6		EN 60974-4, connection type: test socket					
A7		EN 60974-4, connection type: AT16-DI/AT32-DI					
A8		Extension cable (RPE, RISO), passive measurement type, EL1adapter					
Freely co	nfigurable	test sequences					
AUT0		Freely selectable standard, connection type and measurement type					

10 A $R_{P\!E}$ measurements are only possible with line voltages of 115/230 V and line frequencies of 50/60 Hz.

Display with Selectable Language

The display panel consists of a backlit, color multi-display at which menus, setting options, measurement results, instructions and error messages, as well schematic and wiring diagrams appear.

The display and user prompting can be set to the desired language depending on the country in which the test instrument is used.

Data Entry

Data can be entered, for example, via a barcode reader connected to the USB port, a USB keyboard, or via the softkey keyboard when it appears at the display.

Creating a Database

A complete test structure with data regarding customers and test objects can be created in the test instrument. This structure makes it possible to assign single measurements or test sequences to devices under test belonging to various customers. Manual single measurements can be grouped together into a socalled "manual sequence".

Data Interfaces

Structures set up in, and measurement data saved to the test instrument can be imported to ETC report generating software via the USB slave port. Data can then be archived at the PC, comments can be added with the software and reports can be generated.

The following input and output devices can be connected to the two integrated USB master ports:

- An external keyboard and a barcode reader
- A printer

Software Update

The test instrument can always be kept current thanks to firmware which can be updated via the USB slave port. Software is updated during the course of recalibration by our service department, or directly by the customer.

Report Generating Functions

All of the values required for approval reports or device logbooks for electrical equipment (e.g. per ZVEH) can be measured with this instrument.

All measured data can be documented and archived thanks to the measurement and test report that can be printed with a thermal printer connected to the USB port, or stored to a PC.

Automatic Detection of Measuring Point Changes

During protective conductor measurement, the test instrument recognizes whether or not the test probe is in contact with the protective conductor, which is indicated by means of two different acoustic signals. This function is very useful where several protective conductor connections need to be tested.

Mains Connection Analysis

Line voltage and frequency are measured and compared with the data specified in the setup menu. Momentary voltage or nominal voltage in accordance with the standard is required, for instance in order to extrapolate measured values for the leakage current measurement.

Automatic Detection of Mains Connection Errors

The device automatically recognizes mains connection errors if the conditions in the following table have been fulfilled. The user is informed of the type of error, and all measuring functions are disabled in the event of danger.

Type of Connection Error	Message	Condition	Measurements
PE without reference to neutral conductor N or phase conductor L	Display at the instrument		
Voltage at protective conductor PE to fin- ger contact (START/ STOP key)	Display at the instru- ment	Press START/STOP button U > 25 V	All measurements disabled
Protective conductor PE & phase conductor L reversed and/or neutral conductor N interrupted		Voltage at PE > 100 V	Impossible (no supply power)
Line voltage < 180 V / < 90 V (depending on mains)	Reference Voltage adjustable in setup menu	U _{L-N} < 180 V U _{L-N} < 90 V (Reference Voltage adjustable in setup menu)	Possible under cer- tain circumstances

10 A R_{PE} measurements are only possible with line voltages of 115/230 V and line frequencies of 50/60 Hz.

Analysis of DUT Connection and Condition

Depending on the measurement or how the DUT is connected, the following states are checked and displayed before measurement is begun.

Control Function		Condition
Short-circuit test	Short-circuit / starting current	$R \le 1.5 \Omega$
	$R > 1.5 \Omega$	
On test	On (passive DUT)	$R < 250 \text{ k}\Omega$
	Off (active DUT)	$R > 300 \text{ k}\Omega$
Special test	No probe	$R > 2 M\Omega$
	Probe detected	$R < 500 \text{ k}\Omega$
Protection class detection	Protective conductor exists: PC I	R < 1 Ω
	No protective conductor: PC II	R > 10 Ω
Safety shutdown		
Triggered at following residual		> 10 mA / > 30 mA
Triggered at following residual	1	
	Ouring leakage current measurement	> 10 mA
During pi	rotective conductor resistance meas.	> 250 mA
Connection test		
Checks whether the DUT is co	I: checks whether the two protective	
	Protective conductor exists	R < 1 Ω
	No protective conductor	$R > 10 \Omega$
Insulation test		
D	UT set up in a well-insulated fashion	$R \geq 500 \; k\Omega$
DU	I set up in a poorly insulated fashion	$R < 500 \text{ k}\Omega$

Application

Regulations and standards in accordance with which the test instrument is manufactured and tested:


IEC/EN 61010-1:2010	Safety requirements for electrical equipment for measurement, control and laboratory use
VDE 0411-1:2011	– General requirements
DIN VDE 0404, part 1: 2002	Test and measuring equipment for testing the electrical safety of electrical devices – General requirements
DIN VDE 0404, part 2:	 Equipment for testing after repairs and
2002	modifications, or periodic testing
DIN VDE 0404, part 3:	 Equipment for periodic tests and tests prior to commission-
2005	ing medical electrical devices or systems
DIN EN 60529/	Test instruments and test procedures
VDE 0470, part 1	Degrees of protection provided by enclosures (IP code)
DIN EN 61326-1 Vde 0843-20-1	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 1: General requirements

Backlit Multi-Display Samples

Single Test – Initial Screen with Parameters Display



Help – Schematic and Wiring Diagram



Test Function for Test Step in the Test Sequence

Fund	tion				ţ.	
No c	omment entered!		_	-		
	0.01	A	Р	2	W	
U	228.9	۷	S	2	VA	7
f	50.0	Hz	PF	1.00		X
	\checkmark		м	anual rating		Z

Results of a Test Sequence per VDE 0701-0702

Test						$ \bigtriangleup $
VDE0701-0702		24/09/	2013 01:5	8:24 p	m 🗸	
DUT passed!						_A
ShortedCheck L-N Vis. Insp.					~	
RPE	≤300	mΩ	5	mΩ	~	
RINS PC I	≥1.00	MΩ	> 300	MΩ	~	
IPE LN	≤3.50 ▽	mA	5	μA	~	\checkmark

Database Structure - List of Test Results

MEM Navigation	
Database	1/3
🖵 👗 Company GMC	
Len 🖳 DUT 333	\bigtriangleup
30/08/2013 VDE0701-	0702
	0702
	0702
06/09/2013 IPE	
manual sequences	
└── <u></u> 21/10/2013 FT	
	V

Scope of Delivery

Standard version (country-specific)

- 1 SECUTEST Base, SECUTEST Base10 or XTRA test instrument
- 1 Mains power cable
- 1 Test probe, 2 m, not coiled
- 1 USB cable, USB A to USB B, 1.5 m long
- 1 Plug-on alligator clip
- 1 Calibration certificate
- 1 Condensed operating instructions
- 1 Full operating instructions available on the Internet
- 1 ETC report software available on the Internet

The most up-to-date version of ETC can be downloaded free of charge from the **mygmc** page of our website as a ZIP file, if you have registered your test instrument:

http://www.gossenmetrawatt.com

→ Products → Software → Software for Testers → Report Software without Database → ETC → \underline{myGMC}

ETC user Software for PC

ETC offers a wide variety of support options for data acquisition and management.

- Amongst other things, the software acquires all data for reports in accordance with DIN VDE 0701-0702.
- Test reports (ZVEH) can be generated automatically.
- Created structures can be saved.
- Data can be exported to Excel, CSV and XML formats.
- Device selection lists can be edited.

	5 19 99	22.041.0					Profit ETC Cott	miet fur + Seco
TC Explorer	Detail		_					and a set of the
	Eurochaften							
Datenbank		1042201325						
a 🗄 C0004797 Company GOSSEN	Separate V06270142102							
⇒ A C0004798 Company GMC	Separate	(Auto)						
⇒ ⇒ 123 Luffer	1000000000	THE PART AND						
p in 333 Lufter	Main	100						
= 1 50005012 VDE0701-0702	Upe Fad	230 V						
A M0005816 Kurzschlusskor	CONTRACT OF							
A M0005817 Sichtprtg.	hile:	nut defined						
A M0005836 RPE	1000							
	Datum	30 08 2013 10	10.15					
A M0005846 RISO SK1	EAspect	Bestanden						
A M0005854 IPE LN								
- A M0005865 IB LN	Advisience	Heater						
A M0005879 IPE NL	100	ENU Callant						
A M0005890 IB NL		Annual						
A M0005904 Funktionspr.								
I S0005912 VDE0701-0702	Polades						Conditional Condit	of Lindow
+ 1 S0006032 VDE0701-0702	In the second second	and the second se					and the second second second	And in case of the local division of the loc
+ 1 \$0006137	Sector							
» 1 S0006145	Messschrit	to						
1 \$0006162	messsenne	10						
= 1 S0006173	Massadutt	Evelanden	Measureme	Messwert	Measurgastatus	Genzielet.	Benafung .	
124 Bohrmaschine -	Karper Munikordes			-				
- it 124 portmascrime *	Schools HS	Restanden	-	14 m2	Eestanden	c300 =0		
	8001641	Restanden	896	DOE MCL	Destanden	11 00 MCI		
Red Berndt 22	WEDN	Bedander	14.	Ret	Electorden	(150 ml		
	PEN	Bestanden	16+	E gal.	Restanden	4900 pÅ		
		Bestanden	PE-		Elestanden	c1.50 mA		
	8.N.	Restanter .	18-	8 44 8 5 1 A	Neolanden Nicht bewertet	4,00%		
Mandomich es				DUT N	Pacet persente.		+ +	
	Fuldorige							
Mondursich ex		ungen	2	1.				
kóandumich es	Klassifizier	10000000		30				
Klondenich es Status - Hamatis ander Status ander	Klassifizier	list-	Tie	10				
Mondursich ex	Klassifizier	list-	Tip:	1				
Mondamich es Stadar - Namata ander Stadar ander	Klassifizier	list-	Tis Auto Auto Nervitier					

Characteristic Values

Func-	Measured	Meas. Range / Nominal Range of	Reso-	Nominal Voltage	Open- Circuit	Nom. Current	Short- Circuit	Inter- nal Re- sis-	Refer- ence Resis-	Measuring	Intrinsic Error ¹	Overload Capacity				
tion	Quantity	Use	lution	U _N	Voltage U ₀	I _N	Current I _K	tance R _l	tance R _{REF}	Uncertainty ¹		Value	Time			
	Protective	$000\ldots 999~\text{m}\Omega$	1 mΩ				>200 mA					264 V				
	conductor	$1.00 \dots 999 \Omega$	10 m Ω		< 24 V		AC or DC	_	_	±(15% rdg.+ 10 d)	±(10% rdg.+ 10 d)	250 mA	Cont.			
' 51)	resistance R PE	10.0 30.0 Ω	100 m Ω		AC or DC		> 10 A AC 5)			> 10 d	> 10 d	16 A ⁵⁾	0011.			
E 01		10 … 999 kΩ	1 kΩ							±(5% rdg.+ 4 d)	±(2.5% rdg.+2 d)					
٩.	Insulation	1.00 9.99 MΩ	10 kΩ	50 500	1.0 • U _N	. 1	0 1			> 10 d	> 10 d	264 V	0			
23	resistance Riso	10.0 99.9 MΩ	100 kΩ	V DC	1.5 ● Ü _N	> 1 mA	> 2 mA	_	_	≥ 20 MΩ:	≥ 20 MΩ:	264 V	Cont.			
623	1130	100 300 MΩ	1 MΩ							±(10% rdg.+ 8 d)	±(5% rdg.+4 d)					
Ë	Leakage current,	0.0 99 μA	1 μA													
1/(alternative	100 999 μA	1 μA		50			1501.0	1 kΩ	$\pm (5\% \text{ rdg.} + 4 \text{ d}) > 10 \text{ d}$. .			
702	measurement ²	1.00 9.99 mA	10 µA		250 V~ - 20/+10%		> 1.5 mA	$> 150 \text{ k}\Omega$	$\pm 10 \Omega$	> 15 mA: ±(10% rdg.+ 8 d)	> 15 mA: ±(5% rdg.+ 4 d)	264 V	Cont.			
2	IPE, IB, IG, IA	10.0 30.0 mA	100 µA		20/110/0											
Tests, 62638 (DIN VDE 0701-0702) / IEC 62353 (VDE 0751)	Leakage current,	Only lp: 0.0 99.9 μΑ	100 nA													
N	direct	0.0 99 µA	1 μA		_		_	1 kΩ ±10 Ω		±(5% rdg.+ 4 d)	±(2.5% rdg.+2 d) > 10 d	264 V				
ē	measurement ³	100 999 μA	1 μA							> 10 d			Cont.			
638	IPE, IB, IG, IA, IP	1.00 9.99 mA	10 µA													
62		10.0 30.0 mA	100 µA													
sts,	Leakage current,	0 99 μA	1 μA													
Te	differential	100 999 μA	1 μA								1 kΩ	,	±(5% rdg.+ 4 d)	±(2.5% rdg.+2 d)		
	current	1.00 9.99 mA	10 µA		—		—	±10 Ω		> 10 d	> 10 d	264 V	Cont.			
	measurement ⁴ IPE, IB, IG	10.0 30.0 mA	100 µA													
	Line voltage U _{L-N}	100.0 240.0 V~	0.1 V	_	—	_	—	_	—		±(2% rdg.+2 d)	264 V	Cont.			
	Load current I_L	0 16.00 A _{RMS}	10 mA	—	—	—	—	—	—	—	±(2% rdg.+2 d)	16 A	Cont.			
test	Active power P	0 0700 W	1 W								±(5% rdg.+10 d)	264 V	Cont.			
ion	Active power P	0 3700 W	I VV		—			_			> 20 d	20 A	10 min			
Function test	Apparent power S	0 4000 VA	1 VA	Calculated value, $U_{L-N} \bullet I_V$						1	\pm (5% rdg.+10 d) > 20 d					
	Power factor PF with sinusoidal waveform: cosφ	0.00 1.00	0.01			Calculated	l value, P /	S, display >	10 W		±(10% rdg.+5 d)					
	Probe voltage	0.0 99.9 V	100 mV													
UPROBE	(phase search) $$, \sim and $=$	100 300 V	1 V		—					—	±(2% rdg.+2 d)	264 V	Cont.			
t _a PRCD	Time to trip at 30 mA	0.1 999 ms	0.1 ms	_	_	_	_	_	_	±5 ms						

Specified values are only valid for the display at the test instrument. Data transmit-

ted via the USB port may deviate from these values.

2 Known as equivalent leakage current or equivalent patient leakage current from previous standards

Protective conductor current, touch current, device leakage current, patient leakage current Λ

Protective conductor current, touch current, device leakage current Only with SECUTEST Base10 and SECUTEST XTRA with feature G01

Key: rdg. = reading (measured value), d = digit(s)

Test Times, Automated Sequence

Test time > 2 s, exception: device protective conductor resistance RPE: > 7 s. Test times are not checked or calibrated, but rather determined on the basis of processor cycle times.

Emergency Shutdown During Leakage Current Measurement

As of 10 mA of differential current (can also be set to 30 mA), automatic shutdown ensues within 100 ms.

Influencing Quantities and Influence Error

innuencing quantities and innuence Error								
Influencing Quantity / Sphere of Influence	Designation per DIN VDE 0404	Influence Error $\pm \dots \%$ rdg.						
Change of position	E1	—						
Change to test equipment supply voltage	E2	2.5						
Temperature fluctuation	E3	Specified influence error valid starting with temperature changes as of 10 K:						
0 40 °C		2.5						
Amount of current at DUT	E4	2.5						
Low frequency magnetic fields	E5	2.5						
DUT impedance	E6	2.5						
Capacitance during insulation mea- surement	E7	2.5						
Waveform of measured current								
49 51 Hz	E8	2 with capacitive load (for equiva- lent leakage current)						
45 100 Hz		1 (for touch current)						
		2.5 for all other measuring ranges						

Reference Ranges

Line voltage $230 \text{ VAC } \pm 0.2\%$ Line frequency $50 \text{ Hz } \pm 2 \text{ Hz}$ WaveformSine (deviation between effective and rectified value < 0.5%)</td>Ambient+23 °C $\pm 2 \text{ K}$ Relative humidity $40 \dots 60\%$ Load resistanceLinear

Nominal Ranges of Use

Nominal line voltage100 V ... 240 V ACNominal line frequency50 Hz ... 400 HzLine voltagewaveformSinusoidalTemperature0 °C ... + 50 °C

Ambient Conditions

Storage temperature- 20 °C ... + 60 °COperating temperature5 °C ... + 40 °CAccuracy range0 °C ... + 40 °CRelative humidityMax. 75%, no condensation allowedElevationMax. 2000 mDeploymentIndoors, except within specified ambient
conditions

Power Supply

Line voltage	100 V 240 V AC
Line frequency	50 Hz 400 Hz
Power consumption	200 mA test: approx. 32 VA
	10 A test: approx. 105 VA
For function test	Continuous max. 3600 VA, power is con- ducted through the instrument only, switching capacity \leq 16 A, ohmic load

Electrical Safety

	Protection class	l per IEC 61010-1/El VDE 0411-1	N 61010-1/
	Nominal voltage	230 V	
	Test voltage	2.3 kV AC 50 Hz or 3	
_		(mains circuit / test s minal, USB, finger co socket)	ocket to mains PE ter- ontact, probe, test
ges	Measuring category	250 V CAT II	
-	Pollution degree	2	
-	Safety shutdown	At DUT differential cu	,
-		shutdown time: < 10	
-		can also be set to > with following probe	
_		– Leakage current m	8
		> 10 mA~/< 5 ms	
		 Protective conduct > 250 mA~/< 1 ms 	
va-	Fuse links	Mains fuses:	2 ea. 500 V/16 A FF
		Probe fuse:	250 V/250 mA MT
ges		SECUTEST BASE10:	Additionally
5-5			1 ea. 500 V/16 A FF

.....

Electromagnetic Compatibility

Product standard	DIN EN 61326-1
FIUUUUL SLAHUAIU	DIN LIN 01320-1

Interference Emission		Class		
EN 55011		В		
Interference immunity	Test value	Evaluation criterion		
EN 61000-4-2	Contact/atmos. – 4 kV/8 kV	A		
EN 61000-4-3	3 V/m or 1 V/m	A		
EN 61000-4-4	1 kV	В		
EN 61000-4-5	1 kV or 2 kV	A		
EN 61000-4-6	3 V/m	A		
EN 61000-4-11	0.5/1/25 periods	A		
	250 periods	С		

USB Data Interface

4

		tick for dat	a backup,
	for printer		
Mechanical I	Design		
Display	4.3" multi-	-display (9.	7 x 5.5 cm),
	backlit, 48	30 x 272 pi	xels at 24 bit color
	depth (tru	,	
Dimensions			5 x 150 mm
	0	h handle: 1	70 mm
Weight	Approx. 2	0	
Protection	Housing:	IP 40	
	Test sock	et: IP 20 pe	er DIN VDE 0470,
	part 1/EN		
	Table Exce	rpt Regardir	ng Significance of IP
	Codes		
IP XY	Protection Against	IP XY	Protection Against
(1 st digit X)	Foreign Object Ingress	(2 nd digit Y)	Penetration by Water

0

 \geq 1.0 mm dia.

Not protected

Accessories (not included)

Z751A Barcode Reader

For connection to the USB master port at the **SECUT-EST BASE(10)/XTRA** test instrument, and for reading in barcodes. This makes it possible to conveniently



insert the ID numbers of DUTs into single measurements and test sequences.

This device is based upon the concept of an instinctive scanning distance and provides best possible reading performance at distances of up to 20 cm. Green Spot technology provides a "goodread" projection directly on the code. The device is equipped with a USB port.

Z721S Thermal Printer

For connection to the USB master port at the **SECUT-EST BASE(10)/XTRA** test instrument, and for printing out test reports.



EL1 Adapter for Testing Single-Phase Extension Cables



CEE Adapter for Testing Single and 3-Phase Electrical Devices

The Z745A CEE adapter allows for quick and efficient testing of devices equipped with a CEE plug. The adapter is equipped with the following CEE flush-type socket outlets: 5-pole 16 A, 5-pole 32 A and 3-pole 16 A. Furthermore, the adapter includes five 4 mm safety sockets to which 3-phase devices without permanently attached plug or conventional measurement cables can be connected, e.g. by means of quick clamp terminals (not included). The following tests can be performed on devices with CEE plugs with the help of the adapter:

- Testing of protective conductor continuity
- Insulation resistance, alternatively leakage current (equivalent leakage current)
- Function test (3-pole CEE outlet only)

The Z745A CEE adapter may also be used as an adapter for connecting devices with 3-pole CEE plugs to common earthing contact outlets.

AT16-DI (Z750A) 3-Phase 16 A Differential Current Adapter

Devices which are equipped with a 5-pole, 16 A / 6 h CEE plug can be quickly and efficiently tested with the AT16-DI CEE adapter. The following tests can be performed on devices with **CEE** plugs with the help

of the AT16-DI CEE adapter:



- Testing of protective conductor continuity
- Insulation resistance, alternatively leakage current (equivalent leakage current)
- Measurement of protective conductor resistance with the following methods:

equivalent leakage current / differential current / direct

Function test

This differential current adapter is also available in a variant with a 5-pole 32 A / 6 h CEE plug with the designation AT32-DI CEE adapter.

SECU-cal 10 Calibration Adapter

The calibration adapter is used for testing the measuring uncertainty of test instruments in accordance with DIN VDE 0701-0702 / IEC 62353 (VDE 0751). As a rule, these instruments must be tested once each year, as well as for certification in accordance with the ISO 9000 quality standard, as set forth by accident prevention regulation BGV A3 (previously VBG 4).

All limit values for the required tests per DIN VDE, as well as protective conductor resistance, insulation resistance, equivalent leakage current, differential and/or touch as well as housing leakage current, must be tested.

Order Information

SECUTEST BASE and SECUTEST BASE10 Standard Models

Standard Model	Article Number	Features
SECUTEST BASE	M7050-V001	Schuko variant (test socket and mains plug), se- lectable user interface language (default set- ting: German), protective conductor test cur- rent: 200 mA, calibration certificate in D/GB/F, printed condensed operating instructions in German
SECUTEST BASE10	M7050-V002	Schuko variant (test socket and mains plug), se- lectable user interface language (default setting: German), protective conductor test current: 200 mA and 10 A, calibration certificate in D/ GB/F, printed condensed operating instructions in German

Feature-Dependent SECUTEST XTRA Test Instrument Variants

Test instrument with 8 pre-set test sequences per standard and one freely configurable test sequence, selectable user interface language, country-specific test socket, probe cable with test probe, plug-on alligator clip, USB ports, calibration certificate, printed condensed operating instructions, operating instructions for test instrument ETC report software on the Internet.

List of Features

Feature	Test socket and mains plug, country specific	Language for pre-set user interface	R-PE test current	Calibration cer- tificate, lan- guage combina- tion
M7050	В	C	G	Р
00	Schuko	German	200 mA	D/GB/F
01	UK	English	10 A ¹	D/GB/PL
02	CH	French		D/GB/IT
03	FR/CZ	Italian		
04	China	Spanish		
05	USA	Czech		
06	AUS	Dutch		
07	DK	Polish		
08	Italy			

 $^1\,$ 10 A $\rm R_{PE}$ measurements are only possible with line voltages of 115/230 V and line frequencies of 50/60 Hz.

Cells with gray grid: reserved for planned expansions

Designation	Article number	Features
SECUTEST XTRA	M7050	Country-specific variant (test socket and mains plug), selectable user interface language, lan- guage selected as a feature is pre-set upon shipment, protective conductor test current: 200 mA or additionally 10 A depending on fea- ture, calibration certificate with language com- bination depending on feature, printed con- densed operating instructions in user interface language if available, otherwise GB

Order example: M7050 B03 C07 G01 P01

SECUTEST XTRA = M7050

- B03: test socket and mains plug for F and CZ,
- C07: user prompting, keyboard layout
- and test sequences in polish
- P01: calibration certificate in GB/PL

Order Information for Accessories

Designation	Туре	Article number
PC analysis software		
Further information regarding software is av	ailable on the Int	ernet at:
http://www.gossenmetrawatt.com		
$(\rightarrow \text{Products} \rightarrow \text{Software} \rightarrow \text{Software for}$	lesters)	
Data Storage / Report Generating Acces	sories	
Thermal printer for printing out test re-		
ports; inkl. manual on CD, Lithium-Batte- rie, power supply adapter, mains cable,		
USB cable, 1 role of Thermopaper	Z721S	Z721S
Thermo paper for Z721S; 10 roll of thermo	21210	21210
paper, Ø 12/50mm, 30 m x 112 mm, coat-		
ing outside	Z722S	Z722S
Barcode scanner for USB connection	Z751A	Z751A
See also separate ID systems data sheet re	garding barcode	scanners and printers
Accessory Probes, Sensors, Adapters ar	nd Cables	
Probe cable with test probe and 2 m probe	800	77.450
cable (not coiled), 300 V CAT II 16 A	PC2	Z745D
Probe cable with test probe and 2 m probe cable (coiled), 300 V CAT II 16 A	SK2W	Z745N
5 m probe cable for protective conductor	SKZW	Z745IN
measurement, 300 V CAT II 16 A	PC5	Z7450
Brush probe	Z745G	Z745G
Adapter for testing single-phase extension	27430	27430
cables including earth contact and inlet		
plug inserts	EL1	Z723A
Test adapter with single and 3-phase plug		
connectors up to CEE 32A		
- For all tests per DIN VDE without line		
voltage at single and 3-phase electrical		
devices		
 For tests per DIN VDE at single and 3- phase extension cords 	VL2E	Z745W
Adapter for connecting DUTs:	VLZL	L14JW
3-pole 16 A, 5 -pole 16 A + 32 A,		
5 ea. 4 mm socket		
– For all tests per DIN VDE without line		
voltage at single and 3-phase electrical		
devices	CEE Adapter	Z745A
3-phase 16 A differential current adapter	AT16-DI	Z750A
3-phase 32 A differential current adapter	AT32-DI	Z750B
Cable set for connecting test instruments		
to the mains without using a an earthing		
contact outlet, and for connecting DUTs.		
Consists of coupling socket with 3 perma-		
nently connected cables, 3 measurement cables, 3 plug-on pick-up clips and 2 plug-		
on test probes.	KS13	GTY3624065P01
UT 1001 PT0000.	1.010	U113024003F01

Designation	Туре	Article number
Additional Accessories		
Calibration adapter for test instruments per DIN VDE 0701-0702/IEC 62353 (VDE 0751) (max. 200 mA) cannot be used for 10 A protective conductor test		
current	SECU-cal 10	Z715A
Test adapter in combination with SECUTEST for testing welding units per DIN EN 60974-4:2007. The peak value for open circuit voltage is determined in the SECULOAD by means of a peak value rectifier with very fast diodes. As a result, the actual peak value for open- circuit voltage is also read out for pulsed voltage sources with cycle rates within a range of several 10 kHz in consideration of the filter stipulated in the standard. Includes 4 measurement cables and 2 alli- gator clips.	SECULOAD	Z745V
Test adapter in combination with SECUTEST for testing welding units per DIN EN 60974-4:2007. The peak-value rectifier in the SECULOAD- N uses the 1N4007 rectifier diode recom- mended in the standard. This is a mains rectifier diode which, due to its design, is only suitable for voltage sources with low cycle rates within the range of the line frequency, or voltage sources with conventional transformer. Includes 4 measurement cables and 2 alli- gator clips.	SECULOAD-N	Z745R
Carrying pouch for all SECUTEST instru- ments without HV module	F2000 ^D	Z700D

Data sheet available

For additional information regarding accessories please refer to

- Measuring Instruments and Testers catalog
- www.gossenmetrawatt.com

Edited in Germany • Subject to change without notice • A PDF version is available on the Internet



GMC-I Messtechnik GmbH Südwestpark 15 90449 Nürnberg, Germany Phone +49 911 8602-111 Fax: +49 911 8602-777 e-mail: info@gossenmetrawatt.com www.gossenmetrawatt.com